

For Model EW3400/3420/3430



Enable code32

It has influence on code 39 reading, so disable Code 32 when you need to read Code39



Disable code32



Send code32 system character



Hide code32 system character

For Model EW3410

Please scan below setting code to enable Code32



使能 Code32

Enable Code32



*不使能 Code32

Disable Code32