

HP 19V4.74A 4.8mm\*1.7mm 90W

## Compaq

### Armada series

100S, 110, 110S, E300, E500, E500S, E700, M300, M500, M700, V300,

### Evo series

N1000, N1000C, N1000V, N1005V, N110, N150, N200, N400, N400C, N410C, N600, N600C, N610C, N620C, N800, N8000, N800C, N800V,

### Presario series

1500, 1500SC, 1500US, 1501, 1502, 1502SC, 1503, 1505US, 1506, 1507, 1508, 1509, 1510, 1510US, 1511, 1512, 1516, 1520, 1520US, 1522, 1525, 1525US, 1531, 1535, 1538, 1550, 1555, 1568, 1570, 1572, 1580, 2200, 2201AP, 2201US, 2800, 2800CA, 2800US, 2801CL, 2805US, 300, 900, 900US, 905, 905US, 910, 910US, 912, 912RSH, 918, 918RSH, 920, 920US, B3800, C500, F500, M2000, V2000, V2010, V2030, V2100, V2300, V2400, V2500, V2600, V4000, V5000, V6000, V6100, V6200, V6300, V6500, X1000, X1015, X1030, X1040, X1200, X1300,

### Prosignia series

160, 165, 170, 190, 800,

## HP

### Business Notebook series

530, 550, 6720, 6720S, 6720T, 6820S, G5000, G6000, NC4000, NC4010, NC6000, NC6100, NC6105, NC6110, NC6115, NC6120, NC7200, NC8000, NC8230, NW8000, NW8240, NX4800, NX5000, NX5100, NX6100, NX6105, NX6110, NX6115, NX6120, NX6125, NX6130, NX7000, NX7010, NX7040, NX7100, NX7200, NX8000, NX8220, NX8420, NX9020, NX9030, NX9040, NX9050,

### Mini series

311-1000, 311-1000NR, 311-1001XX, 311-1021NR, 311-1022NR, 311-1025NR, 311-1025TU, 311-1028TU, 311-1036TU, 311-1037NR, 311-1037TU, 311-1038NR, 311-1100, 311-1109TU, 311-1110TU,

### Notebook PC series

2000-101XX, 2000-104CA, 2000-120CA, 2000-129CA, 2000-130CA, 2000-140CA, 2000-150CA, 2000-151CA, 2000-208CA, 2000-210US, 2000-211HE, 2000-216NR, 2000-217NR, 2000-219DX, 2000-224CA, 2000-227CL, 2000-228CA, 2000-239DX, 2000-239WM, 2000-240CA, 2000-250CA, 2000-299WM, 2000-300CA, 2000-320CA, 2000-329WM, 2000-340CA, 2000-350US, 2000-351NR, 2000-352NR, 2000-353NR, 2000-354NR, 2000-355DX, 2000-356US, 2000-358NR, 2000-361NR, 2000-363NR, 2000-365DX, 2000-369NR, 2000-369WM, 2000-370CA, 2000-373CA, 2000-379WM, 2000-410US, 2000-412NR, 2000-420CA, 2000-427CL, 2000-450CA, 2000T-300, 2000Z-100, 2000Z-300, 2000Z-400, 2133,

### Pavilion series

DV1000, DV1000-DZ677AV, DV1000-DZ678AV, DV1000-DZ731AV, DV1000T, DV1001AP-PK809AS, DV1001XX-PK807AS, DV1002AP-PF352PA, DV1002XX-PK808AS, DV1003AP-PF353PA, DV1004AP-PF354PA, DV1005AP-PF355PA, DV1006AP-PF356PA, DV1007AP, DV1007AP-PF367PA, DV1008AP, DV1008AP-PF368PA, DV1009AP-PH468PA, DV1009XX-PR284AS, DV1010, DV1010AP-PH476PA, DV1010CA, DV1010CA-PM056UA, DV1010CA-PM056UAR, DV1010US-PM053UAR, DV1011AP, DV1012AP-PD111PA, DV1012LA-PQ641LA, DV1013AP-PD110PA, DV1013AP-PD112PA, DV1014AP-PD113PA, DV1014LA-PP888LA, DV1015AP-PD114PA, DV1015LA-PN713LA, DV1016AP-PD117PA, DV1017AP-PD118PA, DV1018AP-PD119PA, DV1019AP-PD120PA,

DV1010US-PM053UA, DV1020AP-PH482PA, DV1021AP-PH483PA, DV1022AP-PN562PA, DV1023AP-PN563PA, DV1024AP-PN575PA, DV1024LA-PP889LA, DV1025AP-PN576PA, DV1025LA-PN712LA, DV1026AP-PN907PA, DV1027AP-PN578PA, DV1029AP-PN888PA, DV1029AP-PN908PA, DV1030, DV1030AP-PN910PA, DV1031AP-PP963PA, DV1032AP-PP971PA, DV1033AP-PP981PA, DV1034AP-P982PA, DV1035AP-PP989PA, DV1036AP-PS939PA, DV1037AP-PS940PA, DV1040CA, DV1040CA-PM057UA, DV1040CA-PM057UAR, DV1040US-PM054UA, DV1040US-PM054UAR, DV1042QV-PM055UA, DV1044LA-PP890LA, DV1049CL-PM058UA, DV1049CL-PM058UAR, DV1060US-PM059UA, DV1060US-PM059UAR, DV1065US-PM061UA, DV1065US-PM061UAR, DV1067EA-PQ563EA, DV1068EA-PQ564EA, DV1071EA-PQ562EA, DV1100, DV1101AP-PS925PA, DV1102AP-PS926PA, DV1122AP-PV253PA, DV1128AP-PV295PA, DV1134AP, DV1135AP, DV1200, DV1240CA, DV1300-DT111AV, DV1301AP, DV1302AP, DV1303AP, DV1309AP, DV1315CL, DV1317AP, DV1327AP, DV1330CA, DV1331SE, DV1400, DV1500, DV1600, DV2000, DV2000T, DV2000Z, DV2001TU, DV2001TX, DV2001XX, DV2002TU, DV2002TX, DV2002XX, DV2003EA, DV2003TU, DV2003TX, DV2004EA, DV2004TU, DV2004TX, DV2004XX, DV2005EA, DV2005TU, DV2005TX, DV2005XX, DV2006EA, DV2006TU, DV2006TX, DV2006XX, DV2007EA, DV2007TU, DV2007TX, DV2008EA, DV2008TU, DV2008TX, DV2009EA, DV2009TU, DV2009TX, DV2009XX, DV2010EA, DV2010TU, DV2010TX, DV2011EA, DV2011TU, DV2011TX, DV2011XX, DV2012EA, DV2012TU, DV2012TX, DV2013EA, DV2013TU, DV2013TX, DV2014EA, DV2014TU, DV2014TX, DV2015EA, DV2015NR, DV2015TU, DV2015TX, DV2016EA, DV2016TU, DV2016TX, DV2017EA, DV2017TU, DV2017TX, DV2018EA, DV2018TU, DV2018TX, DV2019EA, DV2019TU, DV2019TX, DV2020CA, DV2020EA, DV2020TU, DV2020TX, DV2020US, DV2021TU, DV2021TX, DV2022TU, DV2022US, DV2023TU, DV2024TU, DV2024TX, DV2025LA, DV2025NR, DV2025TU, DV2025TX, DV2026TU, DV2026TX, DV2027TU, DV2027TX, DV2028EA, DV2028TU, DV2028TX, DV2029EA, DV2029TU, DV2029TX, DV2030EA, DV2030TU, DV2030TX, DV2031EA, DV2031TU, DV2031TX, DV2032EA, DV2032TU, DV2032TX, DV2033EA, DV2033TU, DV2033TX, DV2034EA, DV2034TU, DV2034TX, DV2035EA, DV2035LA, DV2035TU, DV2035TX, DV2035US, DV2036EA, DV2036TU, DV2036TX, DV2037TU, DV2037TX, DV2037US, DV2038TU, DV2038TX, DV2039TU, DV2039TX, DV2040CA, DV2040TU, DV2040TX, DV2040US, DV2041TU, DV2041TX, DV2042TU, DV2042TX, DV2043TU, DV2043TX, DV2044TU, DV2044TX, DV2045EA, DV2045TU, DV2046TU, DV2046TX, DV2047CL, DV2047TU, DV2047TX, DV2048TX, DV2049TX, DV2050TU, DV2050TX, DV2050US, DV2053EA, DV2054EA, DV2055EA, DV2056EA, DV2057EA, DV2058EA, DV2064EA, DV2065EA, DV2080EA, DV2081EA, DV2082EA, DV2083EA, DV2084EA, DV2085EA, DV2088XX, DV2095EA, DV2097EA, DV2098EA, DV2099EA, DV2100, DV2101EU, DV2101XX, DV2102XX, DV2103EA, DV2103TU, DV2103XX, DV2104EA, DV2104EU, DV2104NR, DV2104TU, DV2104XX, DV2105EA, DV2105XX, DV2106EA, DV2106EU, DV2108EA, DV2109NR, DV2110EU, DV2110RS, DV2111RS, DV2112RS, DV2115EA, DV2115WM, DV2116, DV2116EA, DV2116TX, DV2116WM, DV2119XX, DV2120, DV2120CA, DV2120LA, DV2120TU, DV2120US, DV2123EU, DV2123TU, DV2125, DV2125EA, DV2125LA, DV2125NR, DV2126EA, DV2129EA, DV2129TX, DV2129US, DV2130, DV2130EA, DV2130TX, DV2130US, DV2131EA, DV2133EA, DV2134EA, DV2134US, DV2135BR, DV2135LA, DV2138XX, DV2140BR, DV2140EU, DV2140TX, DV2141EU, DV2142TX, DV2143TX, DV2145BR, DV2147EA, DV2149EA, DV2150EA, DV2150TX, DV2151TX, DV2152EA, DV2152TX, DV2164EU, DV2166EU, DV2171, DV2171CA, DV2171CL, DV2171EA, DV2172EA, DV2173EA, DV2174, DV2174CL, DV2174EA, DV2175EA, DV2184EA, DV2185EA, DV2190EA, DV2195EU, DV2196EA, DV2197EA, DV2200, DV2200EA, DV2201CA, DV2201XX, DV2202CA, DV2202XX, DV2205EA, DV2207EA, DV2208EA, DV2209EA, DV2209TU, DV2210TU, DV2210US, DV2213CA, DV2213CL, DV2214US, DV2215EA, DV2215TU, DV2216EA, DV2217EA, DV2220US, DV2221US, DV2222EA, DV2222LA, DV2224EA, DV2225NR, DV2227EA, DV2240BR, DV2244EA, DV2245BR, DV2245EA, DV2246EA, DV2247BR, DV2250BR, DV2255BR, DV2260BR, DV2265EA, DV2267EA, DV2268EA, DV2275EA, DV2276EA, DV2278EA, DV2281EA, DV2282EA, DV2297EA, DV2298EA, DV2300, DV2301AU, DV2302AU, DV2303AU, DV2304AU, DV2305AU, DV2306AU, DV2308TU, DV2310CA, DV2310US, DV2312US, DV2313CA, DV2313CL, DV2315NR, DV2315US, DV2317CA, DV2317US, DV2320LA, DV2320US, DV2322LA, DV2325LA, DV2400, DV2401XX, DV2402CA, DV2402TX, DV2402XX, DV2404CA, DV2406TX, DV2407TX, DV2408CA, DV2409TX, DV2410CA, DV2410TX, DV2410US, DV2411TX, DV2412CA, DV2413CA, DV2413CL, DV2414TX, DV2415NR, DV2415TX, DV2415US, DV2416US, DV2418CA, DV2418NR, DV2419US, DV2420LA, DV2420US, DV2422CA, DV2422LA, DV2423LA, DV2425LA, DV2432CA, DV2432NR, DV2500, DV2500T, DV2500TV, DV2500TW, DV2500TX, DV2501XX, DV2502XX, DV2503XX, DV2504XX, DV2505XX, DV2506XX, DV2515TX, DV2525TX, DV2526TX, DV2527TX, DV2528TX, DV2535LA, DV2535TX, DV2539TX, DV2550SE, DV2600, DV2601XX, DV2602CA, DV2602TU, DV2602TX, DV2602XX, DV2604TX, DV2605TX, DV2606TU, DV2606TX, DV2607TU, DV2608CA, DV2608TU, DV2609TU, DV2610CA, DV2610TU, DV2610US, DV2611TU, DV2612CA, DV2612TU, DV2613CL, DV2613TU, DV2613TX, DV2615NR, DV2615US, DV2617US, DV2618CA, DV2619NR, DV2620CA, DV2620US, DV2621LA, DV2622CA, DV2622LA, DV2624LA, DV2625LA, DV2626LA, DV2628TX, DV2629TX, DV2630TX, DV2631TX, DV2633TX, DV2634TX, DV2635LA, DV2635TX, DV2636TX, DV2638TX, DV2639TX, DV2640TX, DV2641TX, DV2642TX, DV2643TX, DV2644TX, DV2660SE, DV2700, DV2700TV, DV2700TW, DV2701XX, DV2702TU, DV2702TX, DV2702XX, DV2703TX, DV2703XX, DV2704TX, DV2704XX, DV2705TU, DV2705TX, DV2706TU, DV2706TX, DV2707TU, DV2707TX, DV2708CA, DV2708TU, DV2708TX, DV2709TU, DV2709TX, DV2710CA, DV2710TU, DV2710TX, DV2712TU, DV2712TX, DV2713CA, DV2713TX, DV2714CA, DV2714TU, DV2714TX, DV2715CA, DV2715NR, DV2715TX, DV2716CA, DV2716TX, DV2717TX, DV2718CA, DV2718TX, DV2718US, DV2719NR, DV2719TX, DV2720TX, DV2721TX, DV2722TX, DV2724CA, DV2725LA, DV2726CA, DV2726LA, DV2727CA, DV2728CA, DV2730TX, DV2734TX, DV2735TX, DV2736TX, DV2736US, DV2737TX, DV2738TX, DV2739TX, DV2740SE, DV2741TX, DV2742SE, DV2745SE, DV2746TX, DV2747TX, DV2748TX, DV2749TX, DV2750TX, DV2751TX, DV2751XX, DV2752TX, DV2752XX, DV2755TX, DV2757TX, DV2759TX, DV2763TX, DV2765TX, DV2766TX, DV2768TX, DV2769TX, DV2770TX, DV2771TX, DV2774TX, DV2779TX, DV2781TX, DV2800T, DV2800TY, DV2801AU, DV2801TU, DV2801TX, DV2801XX, DV2802AU, DV2802TU, DV2802TX, DV2803TU, DV2804CA, DV2804TU, DV2805, DV2805TU, DV2806TU, DV2807NR, DV2807TU, DV2808CA, DV2808TU, DV2809TU, DV2809TX, DV2810CA, DV2810TU, DV2810TX, DV2811TX, DV2812TX,

DV2813TX, DV2814CA, DV2814TX, DV2815NR, DV2816TX, DV2817CA, DV2818CA, DV2818TX, DV2819NR,  
DV2820TX, DV2821TX, DV2823CA, DV2823TX, DV2824TX, DV2825TX, DV2826TX, DV2828CA, DV2829TX,  
DV2830TX, DV2831TX, DV2832TX, DV2833TX, DV2834CA, DV2834TX, DV2835TX, DV2836TX, DV2837TX,  
DV2838TX, DV2839TX, DV2840SE, DV2840TX, DV2841TX, DV2842SE, DV2842TX, DV2845SE, DV2846TX,  
DV2847TX, DV2848TX, DV2849TX, DV2850TX, DV2851XX, DV2854CA, DV2872LA, DV2890CA, DV2890NR,  
DV2894CA, DV2901TU, DV2901TX, DV2902TU, DV2902TX, DV2903TU, DV2904TU, DV2904TX, DV2905TU,  
DV2906TU, DV2907TU, DV2909TX, DV2910CA, DV2911TX, DV2911US, DV2914CA, DV2915CA, DV2915NR,  
DV2915TX, DV2917CA, DV2917CL, DV2917TX, DV2919TX, DV2920TX, DV2921TX, DV2925LA, DV2928CA,  
DV2928SE, DV2940SE, DV2941SE, DV2945SE, DV2946NR, DV2949SE, DV2988NR, DV2988SE, DV2990NR,  
DV2998NR, DV2999NR, DV4-2173NR, DV4000, DV4000-PC253AV, DV4000-PC268AV, DV4000-PC269AV,  
DV4000-PH856AV, DV4000-PH857AV, DV4000-PR496AV, DV4000LA, DV4000XX, DV4000XX-PX249AS,  
DV4001AP-PV281PA, DV4001EA-EB916EA, DV4001XX, DV4001XX-PX248AS, DV4002AP-PV282PA,  
DV4003AP-PV294PA, DV4004AP-PV298PA, DV4004XX, DV4004XX-PX251AS, DV4005AP-PV302PA, DV4005US,  
DV4005US-EA410UA, DV4005XX, DV4006AP-PV303PA, DV4006XX, DV4006XX-PX250AS, DV4007AP,  
DV4007AP-PV304PA, DV4007XX, DV4007XX-PX259AS, DV4008AP-PV316PA, DV4009AP-PV317PA,  
DV4010AP-PV318PA, DV4011AP-PV319PA, DV4012AP-PV320PA, DV4013AP-PV321PA, DV4014AP,  
DV4014AP-PV332PA, DV4014EA-EA037EA, DV4015AP-PV333PA, DV4015CL, DV4015CL-PX306UA,  
DV4015EA-EA034EA, DV4016AP-PY843PA, DV4016EA-EB907EA, DV4017AP, DV4017AP-PY853PA,  
DV4017EA-EA032EA, DV4018AP, DV4018AP-PY854PA, DV4018CL, DV4018EA-EB915EA, DV4019AP-PY881PA,  
DV4019EA-EA033EA, DV4020AP-PY882PA, DV4020EA-EA022EA, DV4020US-PX304UA, DV4021AP-PY883PA,  
DV4021EA, DV4021EA-EB923EA, DV4022AP, DV4022AP-ED099PA, DV4022EA-EB926EA, DV4023AP-ED100PA,  
DV4023EA-EB917EA, DV4024AP, DV4024AP-ED102PA, DV4024EA-EB924EA, DV4025AP-EE547PA,  
DV4025EA-EA036EA, DV4026AP-EE548PA, DV4027EA-EA038EA, DV4030CA, DV4030CA-PX311UA, DV4030EA,  
DV4030EA-EA021EA, DV4030EA-EB914EA, DV4030US, DV4030US-PX302UA, DV4031EA-EB910EA, DV4040CA,  
DV4040CA-PX308UA, DV4040EA-EB920EA, DV4040US, DV4040US-PX303UA, DV4043EA-EA030EA,  
DV4043EA-EB912EA, DV4045EA, DV4045EA-EA027EA, DV4045EA-EB919EA, DV4046EA-EA028EA,  
DV4049EA-EB921EA, DV4050EA-EA025EA, DV4051EA-EB918EA, DV4052EA-EB911EA, DV4054EA-EB913EA,  
DV4056EA-EA039EA, DV4057EA-EA029EA, DV4060EA-EA023EA, DV4070EA, DV4070EA-EB925EA,  
DV4073EA-EB908EA, DV4075EA-EA024EA, DV4078EA-EA026EA, DV4080EA-EB922EA, DV4085EA-EA031EA,  
DV4086EA-EA035EA, DV4100, DV4100-EA292AV, DV4100-EA294AV, DV4101AP, DV4101AP-PY885PA, DV4102AP,  
DV4102AP-PY896PA, DV4102EA-EH187EA, DV4103AP-PY905PA, DV4103EA-EF177EA, DV4104AP-PY906PA,  
DV4105AP-PY907PA, DV4106AP-ED098PA, DV4107AP-ED144PA, DV4108AP-ED145PA, DV4108EA-EF175EA,  
DV4109AP-ED146PA, DV4109EA-EH197EA, DV4110AP, DV4110AP-ED142PA, DV4110EA-EH725EA, DV4111AP,  
DV4111AP-ED143PA, DV4112AP-ED147PA, DV4113AP-ED148PA, DV4113EA-EH726EA, DV4114AP,  
DV4114AP-ED149PA, DV4115AP, DV4115AP-ED150PA, DV4115EA-EF190EA, DV4116AP-ED171PA, DV4117AP,  
DV4117AP-ED172PA, DV4118AP-ED174PA, DV4119AP-EE452PA, DV4120AP-EE483PA, DV4121AP,  
DV4121AP-EE501PA, DV4122AP-EE500PA, DV4122EA-EF186EA, DV4123AP-EE517PA, DV4124AP-EE518PA,  
DV4125AP, DV4125AP-EE524PA, DV4125EA-EH185EA, DV4125US, DV4125US-EC325UA, DV4126AP-EE528PA,  
DV4126EA-EH183EA, DV4127AP-EE529PA, DV4128AP, DV4128AP-EE553PA, DV4128EA-EH191EA, DV4129AP,  
DV4129AP-EH019PA, DV4129EA-EH730EA, DV4129US, DV4130AP, DV4130AP-EH020PA, DV4130EA,  
DV4130EA-EF171EA, DV4130US, DV4130US-EC317UA, DV4131EA-EF182EA, DV4134EA-EH180EA,  
DV4135EA-EH724EA, DV4136EA-EF183EA, DV4137EA-EH192EA, DV4138EA-EF188EA, DV4139EA-EK552EA,  
DV4140EA-EF178EA, DV4141EA-EH731EA, DV4142EA-EH188EA, DV4143EA-EF179EA, DV4144EA-EK553EA,  
DV4145EA-EF176EA, DV4146EA-EH182EA, DV4146EA-EH727EA, DV4148EA-EK551EA, DV4149EA-EH181EA,  
DV4150CA-EC322UA, DV4150EA, DV4150EA-EF172EA, DV4150US, DV4150US-EC316UA, DV4151EA-EF185EA,  
DV4152EA-EF173EA, DV4152EA-EH196EA, DV4153EA-EH178EA, DV4154EA-EH179EA, DV4155CL,  
DV4155CL-EC321UA, DV4155EA-EH186EA, DV4155US, DV4155US-EC324UA, DV4156EA-EH194EA,  
DV4157EA-EH732EA, DV4158EA-EF184EA, DV4159EA-EH729EA, DV4160EA-EH728EA, DV4161EA-EF180EA,  
DV4162EA-EH189EA, DV4163EA-EF174EA, DV4164EA-EH184EA, DV4165CL, DV4165CL-EC318UA,  
DV4165EA-EF187EA, DV4170CA-EC320UA, DV4170US, DV4170US-EC315UA, DV4174EA-EH733EA,  
DV4176EA-EH190EA, DV4178EA-EF189EA, DV4180US-EC327UA, DV4182EA-EH195EA, DV4199EA-EF181EA,  
DV4200, DV4201TU, DV4201TX, DV4201XX, DV4202TU, DV4202XX, DV4203EA-EK915EA, DV4203TX, DV4203XX,  
DV4205TX, DV4206TX, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX,  
DV4213TX, DV4214TX, DV4215TX, DV4217CL, DV4218TX, DV4220TX, DV4221TX, DV4222TX, DV4223CL,  
DV4223TX, DV4224EA, DV4225NR, DV4226TX, DV4230US, DV4230US-EC329UA, DV4231EA, DV4250US,  
DV4253US, DV4257US, DV4268EA, DV4269US, DV4270US, DV4272US, DV4275NR, DV4302EA, DV4304EA,  
DV4305EA, DV4305US, DV4306EA, DV4307CA, DV4307CL, DV4308WM, DV4309EA, DV4310US, DV4312EA,  
DV4315EA, DV4318EA, DV4320US, DV4321EA, DV4322EA, DV4324EA, DV4325EA, DV4326EA, DV4327EA,  
DV4330CA, DV4330US, DV4334EA, DV4335EA, DV4335NR, DV4336EA, DV4337EA, DV4339EA, DV4340US,  
DV4342EA, DV4344EA, DV4346EA, DV4348EA, DV4350EA, DV4351EA, DV4353EA, DV4354EA, DV4356EA,  
DV4357EA, DV4358EA, DV4360EA, DV4363EA, DV4364EA, DV4365EA, DV4367EA, DV4368EA, DV4376EA,  
DV4378EA, DV4379EA, DV4381EA, DV4383EA, DV4384EA, DV4385EA, DV4386EA, DV4388EA, DV4391EA,  
DV4392EA, DV4394EA, DV4395EA, DV4396EA, DV4398EA, DV4400, DV4401RS, DV4401XX, DV4402TU, DV4405NR,  
DV4410US, DV4419US, DV4420CA, DV4420US, DV4435EA, DV4440EA, DV4445EA, DV4450EA, DV5000, DV5000EA,  
DV5000T, DV5000Z, DV5001XX, DV5002EA, DV5003CL, DV5003EA, DV5005EA, DV5006EA, DV5007EA, DV5008EA,  
DV5009EA, DV5010EA, DV5011EA, DV5012EA, DV5016EA, DV5017CL, DV5017EA, DV5018EA, DV5020CA,  
DV5020US, DV5021EA, DV5022EA, DV5023EA, DV5024EA, DV5026EA, DV5027EA, DV5029US, DV5030US,  
DV5031EA, DV5033EA, DV5034EA, DV5035EA, DV5035NR, DV5036EA, DV5037EA, DV5040US, DV5041EA,  
DV5046EA, DV5047EA, DV5050EA, DV5051EA, DV5052EA, DV5053EA, DV5054EA, DV5055EA, DV5056EA,

DV5057EA, DV5058EA, DV5059EA, DV5061EA, DV5062EA, DV5063EA, DV5074EA, DV5075EA, DV5077EA,  
DV5078EA, DV5084EA, DV5088XX, DV5091EA, DV5092EA, DV5093EA, DV5094EA, DV5095EA, DV5096EA,  
DV5097EA, DV5098EA, DV5099EA, DV5099XX, DV5100, DV5102EU, DV5104EU, DV5106EU, DV5107TX, DV5109TX,  
DV5110CA, DV5110TX, DV5110US, DV5111TU, DV5111TX, DV5113EU, DV5113TX, DV5114EU, DV5115EU,  
DV5115NR, DV5116EU, DV5116NR, DV5117CA, DV5117CL, DV5119EU, DV5119TX, DV5120EA, DV5120EU,  
DV5120LA, DV5120US, DV5121EA, DV5121EU, DV5122EA, DV5122TX, DV5123EA, DV5123TX, DV5124EU,  
DV5124TX, DV5125EU, DV5125TX, DV5127EU, DV5127TX, DV5128EU, DV5128TX, DV5129EU, DV5129US,  
DV5130CA, DV5130EU, DV5130TX, DV5130US, DV5131EU, DV5131TX, DV5132EU, DV5132TX, DV5134EA,  
DV5134EU, DV5135EU, DV5135NR, DV5136EU, DV5137EA, DV5139US, DV5140CA, DV5140EA, DV5140EU,  
DV5140US, DV5142EA, DV5143EA, DV5144EA, DV5145EA, DV5147EA, DV5148EA, DV5149EA, DV5149EU,  
DV5150EA, DV5150US, DV5155EU, DV5156EU, DV5157EA, DV5157EU, DV5158EU, DV5159EU, DV5161EU,  
DV5163CL, DV5164EA, DV5165EA, DV5166EA, DV5167CL, DV5170US, DV5173EA, DV5173EU, DV5174EU,  
DV5176EA, DV5176EU, DV5177EA, DV5178EA, DV5178US, DV5179EA, DV5186EU, DV5189EU, DV5189XX,  
DV5190EA, DV5190US, DV5191EA, DV5192EA, DV5193EA, DV5194EA, DV5196EA, DV5196XX, DV5197EA,  
DV5198EA, DV5198XX, DV5199XX, DV5200, DV5200TU, DV5201TX, DV5202TX, DV5203TX, DV5204TX, DV5205EA,  
DV5205TX, DV5205TX, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210EA, DV5210TX, DV5210US,  
DV5211EA, DV5211TX, DV5212TX, DV5213TX, DV5214TX, DV5215TX, DV5215US, DV5216CA, DV5216TX,  
DV5217CL, DV5218NR, DV5220LA, DV5220TX, DV5220US, DV5221TX, DV5222NR, DV5222TX, DV5223OM,  
DV5224NR, DV5224TX, DV5225EA, DV5225TX, DV5226TX, DV5229OM, DV5229TX, DV5230US, DV5233TX,  
DV5234US, DV5236OM, DV5237CL, DV5238EA, DV5239EA, DV5240US, DV5243EU, DV5250US, DV5252EA,  
DV5269EA, DV5270EA, DV5271EA, DV5272EA, DV5273EA, DV5278EA, DV5283EA, DV5284EA, DV5298XX,  
DV5299XX, DV5300, DV6000, DV6000T, DV6000Z, DV6001EA, DV6001XX, DV6002XX, DV6003EA, DV6003XX,  
DV6004EA, DV6005EA, DV6006EA, DV6007EA, DV6010EA, DV6011EA, DV6012EA, DV6013EA, DV6014EA,  
DV6015EA, DV6016EA, DV6017EA, DV6018EA, DV6019EA, DV6020EA, DV6021EA, DV6022EA, DV6023EA,  
DV6024EA, DV6025EA, DV6040CA, DV6040US, DV6045NR, DV6054EA, DV6057EA, DV6058CL, DV6058EA,  
DV6059EA, DV6060EA, DV6061EA, DV6062EA, DV6063EA, DV6064EA, DV6065EA, DV6067EA, DV6086EA,  
DV6087EA, DV6088EA, DV6095EA, DV6097EA, DV6100, DV6100EA, DV6101EA, DV6101EU, DV6101TU, DV6101TX,  
DV6101XX, DV6102EA, DV6102EU, DV6102OD, DV6102TX, DV6102XX, DV6103EA, DV6103EU, DV6103NR,  
DV6103TX, DV6103XX, DV6104EA, DV6104EU, DV6104NR, DV6104TX, DV6105CA, DV6105EA, DV6105EU,  
DV6105TX, DV6105US, DV6106EA, DV6106EU, DV6106TX, DV6107EA, DV6107EU, DV6107TX, DV6107US,  
DV6108EA, DV6108NR, DV6108TX, DV6108US, DV6109EA, DV6109NR, DV6109OM, DV6109TX, DV6110BR,  
DV6110CA, DV6110EA, DV6110EU, DV6110TX, DV6110US, DV6111EA, DV6111EU, DV6111NR, DV6111TX,  
DV6112EA, DV6112TX, DV6113CA, DV6113EA, DV6113EU, DV6113TX, DV6113US, DV6114EA, DV6114TX,  
DV6115CA, DV6115EA, DV6115EU, DV6115NR, DV6115TX, DV6116EA, DV6116EU, DV6116NR, DV6116TX,  
DV6117EA, DV6117EU, DV6117TX, DV6118EA, DV6118EU, DV6118NR, DV6118TX, DV6119EA, DV6119EU,  
DV6119TX, DV6119US, DV6120BR, DV6120CA, DV6120EA, DV6120EU, DV6120LA, DV6120SE, DV6120TX,  
DV6120US, DV6121EA, DV6121EU, DV6121TX, DV6122EA, DV6122TX, DV6123EA, DV6123EU, DV6123TX,  
DV6124EA, DV6124EU, DV6124TX, DV6125BR, DV6125EA, DV6125OM, DV6125SE, DV6125TX, DV6126EA,  
DV6126EU, DV6126TX, DV6127EA, DV6127EU, DV6127TX, DV6128EA, DV6128EU, DV6128OD, DV6128TX,  
DV6129EA, DV6129EU, DV6129TX, DV6129US, DV6130CA, DV6130EA, DV6130EU, DV6130TX, DV6130US,  
DV6131EA, DV6131EU, DV6131OD, DV6131TX, DV6132EA, DV6132EU, DV6132TX, DV6133EA, DV6133EU,  
DV6133OD, DV6133TX, DV6134EA, DV6134EU, DV6134TX, DV6135CA, DV6135EA, DV6135EU, DV6135NR,  
DV6135TX, DV6136EA, DV6136EU, DV6136TX, DV6137EA, DV6137EU, DV6137TX, DV6138EA, DV6138EU,  
DV6138TX, DV6139EA, DV6139EU, DV6139TX, DV6139US, DV6140CA, DV6140EA, DV6140EU, DV6140TX,  
DV6140US, DV6141EA, DV6141EU, DV6141TX, DV6142EA, DV6142EU, DV6142TX, DV6143EA, DV6143EU,  
DV6143TX, DV6144EA, DV6144EU, DV6144TX, DV6145EA, DV6145EU, DV6145TX, DV6146EA, DV6146EU,  
DV6146TX, DV6147EA, DV6147EU, DV6147TX, DV6148EA, DV6148EU, DV6148TX, DV6149EA, DV6149EU,  
DV6149TX, DV6149US, DV6150BR, DV6150CA, DV6150EA, DV6150EU, DV6150TX, DV6150US, DV6151EA,  
DV6151EU, DV6152EA, DV6152EU, DV6153EA, DV6153EU, DV6154EA, DV6154EU, DV6155EA, DV6155EU,  
DV6156EA, DV6156EU, DV6157EA, DV6157EU, DV6158EA, DV6158EU, DV6159EA, DV6159EU, DV6160EA,  
DV6160EU, DV6161EA, DV6161EU, DV6162EA, DV6163EA, DV6164EA, DV6165CL, DV6165EA, DV6165EU,  
DV6166EA, DV6167EA, DV6168EA, DV6169EA, DV6170EA, DV6171CL, DV6171EA, DV6172EA, DV6173EA,  
DV6174CA, DV6174CL, DV6174EA, DV6175EA, DV6179EA, DV6180EA, DV6181EA, DV6182EA, DV6182EU,  
DV6183EA, DV6184EA, DV6184EU, DV6185EA, DV6185EU, DV6186EA, DV6186EU, DV6187EA, DV6187EU,  
DV6188EA, DV6188EU, DV6189EA, DV6189EU, DV6190EU, DV6191EU, DV6195EA, DV6195XX, DV6196EA,  
DV6196XX, DV6197EA, DV6197XX, DV6198XX, DV6199XX, DV6200, DV6200EA, DV6200XX, DV6201EA, DV6201EU,  
DV6202EU, DV6203EA, DV6203TX, DV6204EA, DV6204EU, DV6205CA, DV6205EU, DV6205US, DV6206EA,  
DV6206US, DV6208EA, DV6208NR, DV6208TX, DV6210EA, DV6210TX, DV6211EA, DV6212EA, DV6213CL,  
DV6213EA, DV6214EA, DV6215CA, DV6215EA, DV6215TX, DV6215US, DV6216EA, DV6216TX, DV6217EA,  
DV6218EA, DV6218TX, DV6219EA, DV6220BR, DV6220EU, DV6221TX, DV6223EU, DV6225EU, DV6225US,  
DV6226US, DV6227CL, DV6230BR, DV6230EA, DV6231EA, DV6231EU, DV6233EA, DV6233SE, DV6235CA,  
DV6235EU, DV6235NR, DV6235US, DV6236EA, DV6236US, DV6237EA, DV6238EA, DV6239EA, DV6239EU,  
DV6240EU, DV6241EA, DV6241EU, DV6242EA, DV6242EU, DV6243CL, DV6243EA, DV6243EU, DV6244EA,  
DV6244EU, DV6244US, DV6245CA, DV6245EA, DV6245EU, DV6247CA, DV6247CL, DV6247EA, DV6247EU,  
DV6248EU, DV6249EU, DV6250EU, DV6251EU, DV6252EU, DV6253CL, DV6253EU, DV6254EA, DV6254EU,  
DV6255CA, DV6255EU, DV6255US, DV6256EU, DV6256US, DV6258SE, DV6259EU, DV6260EU, DV6262EU,  
DV6263CL, DV6263EU, DV6264EU, DV6265CA, DV6265EA, DV6265EU, DV6265US, DV6266EU, DV6267CL,  
DV6267EU, DV6269EU, DV6274EA, DV6275EA, DV6275US, DV6276EA, DV6276EU, DV6277EA, DV6278EU,  
DV6280EA, DV6281EA, DV6283EU, DV6284EU, DV6285EU, DV6286EA, DV6286EU, DV6287EU, DV6288EA,

DV6290EA, DV6291EA, DV6295EU, DV6297EA, DV6298EA, DV6299EA, DV6299XX, DV6300, DV6303TU, DV6305CA, DV6305US, DV6306RS, DV6307CA, DV6308CA, DV6308NR, DV6315CA, DV6324US, DV6325CA, DV6325US, DV6326US, DV6335CA, DV6335US, DV6337CL, DV6337US, DV6338SE, DV6340EU, DV6345US, DV6353CA, DV6353CL, DV6353US, DV6355CA, DV6355US, DV6357EU, DV6358SE, DV6363CA, DV6365US, DV6375US, DV6399XX, DV6400, DV6400A, DV6401CA, DV6401TU, DV6401TX, DV6401XX, DV6402CA, DV6402TU, DV6402XX, DV6403CL, DV6404CA, DV6404TX, DV6405CA, DV6405US, DV6406CA, DV6406NR, DV6407NR, DV6408CA, DV6408NR, DV6409CA, DV6409US, DV6409WM, DV6410CA, DV6415CA, DV6415US, DV6416CA, DV6418CA, DV6420LA, DV6422LA N, DV6423OM, DV6424CA, DV6425CA, DV6425US, DV6426CA, DV6426US, DV6427CL, DV6428CA, DV6433CL, DV6435CA, DV6436NR, DV6439NR, DV6445US, DV6446US, DV6447OM, DV6448SE, DV6449US, DV6450US, DV6451US, DV6452SE, DV6458SE, DV6470US, DV6499XX, DV6500, DV6500T, DV6500Z, DV6501AU, DV6501XX, DV6502XX, DV6503AU, DV6503TU, DV6504AU, DV6505AU, DV6505TU, DV6513TX, DV6514TX, DV6518TX, DV6520TX, DV6521TX, DV6523TX, DV6524TX, DV6531TX, DV6540TX, DV6541TX, DV6542TX, DV6545TX, DV6547EA, DV6550TX, DV6560US, DV6563CL, DV6565CA, DV6565US, DV6567CL, DV6568SE, DV6570US, DV6573CL, DV6575CA, DV6575US, DV6585CA, DV6589US, DV6597XX, DV6598XX, DV6599XX, DV6600, DV6601AU, DV6601TU, DV6601TX, DV6602AX, DV6603AX, DV6603CA, DV6604AU, DV6604CL, DV6604NR, DV6604TU, DV6604TX, DV6605CA, DV6605US, DV6607CL, DV6607NR, DV6607RS, DV6608CA, DV6609WM, DV6610TX, DV6611CA, DV6611TX, DV6612CA, DV6613TX, DV6615TX, DV6616TX, DV6618CA, DV6618TX, DV6619TX, DV6620LA, DV6620TX, DV6621TX, DV6622CA, DV6622TX, DV6623CL, DV6623TX, DV6624CA, DV6624TX, DV6625CA, DV6625TX, DV6625US, DV6626CA, DV6626TX, DV6626US, DV6627CA, DV6627NR, DV6627OM, DV6628TX, DV6628US, DV6629CA, DV6629TX, DV6629US, DV6629WM, DV6631CA, DV6633US, DV6634NR, DV6636NR, DV6640BR, DV6640US, DV6642CA, DV6643CL, DV6645CA, DV6645US, DV6646US, DV6647CL, DV6647NR, DV6648SE, DV6651XX, DV6652XX, DV6653CL, DV6654US, DV6660SE, DV6661SE, DV6662SE, DV6663CA, DV6663CL, DV6663US, DV6670CA, DV6672US, DV6675US, DV6693US, DV6696NR, DV6699XX, DV6700, DV6700T, DV6700Z, DV6701AX, DV6701CA, DV6701TU, DV6701TX, DV6701US, DV6701VX, DV6701XX, DV6702AU, DV6702AX, DV6702TU, DV6702TX, DV6702VX, DV6703AU, DV6703AX, DV6703TU, DV6703VX, DV6704AU, DV6704AX, DV6704CA, DV6704NR, DV6704TX, DV6704VX, DV6705AX, DV6705CA, DV6705TU, DV6705TX, DV6705VX, DV6706AU, DV6706AX, DV6707AX, DV6707TX, DV6707US, DV6708AX, DV6708TX, DV6709TX, DV6710AX, DV6710TX, DV6711AX, DV6713CA, DV6714CA, DV6714TX, DV6715TX, DV6716CA, DV6716TX, DV6717TX, DV6718CA, DV6718TX, DV6719TX, DV6720LA, DV6720TX, DV6721LA, DV6721TX, DV6722LA, DV6722TX, DV6724CA, DV6725CA, DV6725TX, DV6725US, DV6726TX, DV6727CA, DV6727TX, DV6728CA, DV6728TX, DV6729CA, DV6729TX, DV6729US, DV6730TX, DV6731TX, DV6732TX, DV6734TX, DV6735TX, DV6736NR, DV6736TX, DV6737TX, DV6739TX, DV6740TX, DV6742TX, DV6743TX, DV6744CA, DV6744TX, DV6745TX, DV6745US, DV6746CA, DV6747CL, DV6747NR, DV6748CA, DV6748US, DV6749TX, DV6750TX, DV6751TX, DV6751US, DV6751XX, DV6753CA, DV6753CL, DV6753TX, DV6754TX, DV6755CA, DV6755US, DV6756US, DV6757CA, DV6758US, DV6759TX, DV6762TX, DV6763TX, DV6764TX, DV6765TX, DV6766TX, DV6768TX, DV6769TX, DV6770SE, DV6770TX, DV6771TX, DV6772NR, DV6772TX, DV6775TX, DV6775US, DV6776TX, DV6777TX, DV6778TX, DV6779TX, DV6780CA, DV6780SE, DV6780TX, DV6781TX, DV6782TX, DV6783TX, DV6784TX, DV6785CA, DV6785SE, DV6785TX, DV6786TX, DV6787TX, DV6788TX, DV6789TX, DV6790TX, DV6791TX, DV6792TX, DV6793TX, DV6794TX, DV6795TX, DV6796TX, DV6797TX, DV6800, DV6801AX, DV6801CA, DV6801TU, DV6801TX, DV6802AX, DV6802TU, DV6802TX, DV6803AX, DV6803TU, DV6803TX, DV6804AX, DV6804TU, DV6804TX, DV6805CA, DV6805TU, DV6805TX, DV6806TX, DV6807TX, DV6807US, DV6808TX, DV6809US, DV6809WM, DV6810TX, DV6810US, DV6811TX, DV6812NR, DV6814CA, DV6815NR, DV6815TX, DV6816TX, DV6817TX, DV6818CA, DV6818TX, DV6819TX, DV6820TX, DV6821TX, DV6822TX, DV6823TX, DV6823US, DV6824CA, DV6824TX, DV6825CA, DV6825TX, DV6827CA, DV6827TX, DV6828TX, DV6829TX, DV6830TX, DV6830US, DV6831TX, DV6832TX, DV6833TX, DV6833US, DV6834CA, DV6834TX, DV6835CA, DV6835NR, DV6835TX, DV6836TX, DV6837CL, DV6837TX, DV6838CA, DV6838NR, DV6838TX, DV6839CL, DV6839TX, DV6840TX, DV6841TX, DV6847TX, DV6848TX, DV6851XX, DV6853CA, DV6853CL, DV6854CA, DV6858CA, DV6864CA, DV6870US, DV6871US, DV6872LA, DV6874CA, DV6875CA, DV6875SE, DV6880SE, DV6883CL, DV6884CA, DV6885CA, DV6885SE, DV6898CA, DV6899XX, DV6900, DV6901TU, DV6901TX, DV6902TU, DV6902TX, DV6903TU, DV6903TX, DV6904CA, DV6907CA, DV6907TX, DV6908TX, DV6909TX, DV6910CA, DV6911OM, DV6911US, DV6912TX, DV6913CA, DV6913RS, DV6915CA, DV6915NR, DV6916TX, DV6917CL, DV6917NR, DV6917TX, DV6918SE, DV6918TX, DV6919CA, DV6919TX, DV6920TX, DV6921TX, DV6923TX, DV6926NR, DV6928US, DV6929NR, DV6929WM, DV6930US, DV6933CL, DV6934CA, DV6935CA, DV6936US, DV6937CL, DV6938SE, DV6939CA, DV6940SE, DV6948CA, DV6958SE, DV6968CA, DV6974CA, DV6976CA, DV6985SE, DV6988CA, DV6995LA, DV6998CA, DV8000, DV8000T, DV8000Z, DV8002EA, DV8005EA, DV8010EA, DV8013CL, DV8013XX, DV8027EA, DV8028EA, DV8029EA, DV8035EA, DV8040US, DV8040XX, DV8045EA, DV8051EA, DV8075EA, DV8088US, DV8099XX, DV80XXUS, DV8100, DV8102EA, DV8110US, DV8113CL, DV8113EA, DV8114EA, DV8116EA, DV8117EA, DV8120CA, DV8125NR, DV8130US, DV8135EA, DV8135NR, DV8140US, DV8155EA, DV8173EA, DV8175EA, DV8176EA, DV8177EA, DV8178EA, DV8179EA, DV8195EA, DV8197EA, DV8199EA, DV81XXUS, DV8200, DV8201TX, DV8202TX, DV8203TX, DV8204TX, DV8205TX, DV8206TX, DV8207TX, DV8208TX, DV8209TX, DV8210CA, DV8210EA, DV8210US, DV8211EA, DV8211EU, DV8212EA, DV8213CL, DV8213EA, DV8214EA, DV8214TX, DV8215EA, DV8215TX, DV8219EA, DV8220CA, DV8220EA, DV8220US, DV8221EA, DV8222EA, DV8223EA, DV8225CA, DV8225EA, DV8225NR, DV8226EA, DV8227EA, DV8228EA, DV8229EA, DV8230CA, DV8230EA, DV8230US, DV8231EA, DV8233CL, DV8233EA, DV8235EA, DV8235NR, DV8240US, DV8251EA, DV8252EU, DV8253EA, DV8254EA, DV8260EA, DV8275EA, DV8275LA, DV8279EA, DV8280EA, DV8280US, DV8286EA, DV8287EA, DV8289EA, DV8289XX, DV8290EA, DV8291EA, DV8292EA, DV8293EA, DV8294EA, DV8295EA, DV8298EA, DV8298XX, DV8299XX, DV8300, DV8300TX, DV8301NR, DV8301TX, DV8302TX, DV8304TX, DV8305CA, DV8305TX, DV8305US, DV8306EA, DV8306TX, DV8307EA, DV8307TX, DV8309US, DV8310US, DV8312TX, DV8314TX, DV8315NR,

DV8315TX, DV8318TX, DV8320EA, DV8320US, DV8321TX, DV8322EA, DV8323EA, DV8325EA, DV8327CA,  
DV8327CL, DV8327US, DV8328CA, DV8333CL, DV8339US, DV8375LA, DV8379EA, DV8380US, DV8382EA,  
DV8389EA, DV8390EA, DV8391EA, DV8393EA, DV8395EA, DV8398EA, DV8399XX, DV8400, DV8408US, DV9000,  
DV9000EA, DV9000T, DV9000Z, DV9001EA, DV9001XX, DV9002EA, DV9002NR, DV9002XX, DV9003EA, DV9003TX,  
DV9003XX, DV9004EU, DV9004TX, DV9004XX, DV9005CA, DV9005EA, DV9005TX, DV9005US, DV9005XX,  
DV9006EA, DV9006OM, DV9006TX, DV9008EA, DV9008NR, DV9009CA, DV9009CL, DV9009NR, DV9009TX,  
DV9009US, DV9010CA, DV9010TX, DV9010US, DV9011TX, DV9012TX, DV9013CA, DV9013CL, DV9013TX,  
DV9014EA, DV9014TX, DV9015EA, DV9015TX, DV9016EA, DV9016TX, DV9017EA, DV9017TX, DV9018EA,  
DV9019EA, DV9019TX, DV9020TX, DV9021TX, DV9022EA, DV9022TX, DV9023US, DV9024EA, DV9030EA,  
DV9030US, DV9035EA, DV9035NR, DV9036EA, DV9037EA, DV9038EA, DV9039EA, DV9040EA, DV9040EU,  
DV9040US, DV9041EA, DV9042EA, DV9043EA, DV9044EA, DV9045EA, DV9046EA, DV9048EA, DV9049EA,  
DV9050EA, DV9051EA, DV9052EA, DV9053EA, DV9055EA, DV9056EA, DV9057EA, DV9058EA, DV9059EA,  
DV9060EA, DV9060US, DV9061EA, DV9062EA, DV9063EA, DV9064EA, DV9065EA, DV9066EA, DV9067EA,  
DV9068EA, DV9069EA, DV9071EA, DV9072EA, DV9073EA, DV9074CL, DV9074EA, DV9075EA, DV9075EU,  
DV9075LA, DV9076EA, DV9076EU, DV9077EA, DV9077EU, DV9078EA, DV9079EA, DV9080EA, DV9081EA,  
DV9082EA, DV9082EU, DV9083EA, DV9084EA, DV9085EA, DV9085EU, DV9086EA, DV9087EA, DV9088EA,  
DV9089EA, DV9090EA, DV9091EA, DV9092EA, DV9093EA, DV9093EU, DV9094EA, DV9095EU, DV9095XX,  
DV9096EA, DV9096XX, DV9097EA, DV9097XX, DV9098XX, DV9099EA, DV9099XX, DV9100, DV9200, DV9200XX,  
DV9201CA, DV9201TX, DV9202EA, DV9202TX, DV9204TX, DV9205CA, DV9205EU, DV9205US, DV9206EU,  
DV9206TX, DV9207TX, DV9207US, DV9208NR, DV9208TX, DV9209TX, DV9210CA, DV9210TX, DV9210US,  
DV9211EA, DV9211TX, DV9212EA, DV9212TX, DV9213EA, DV9213TX, DV9214EA, DV9214TX, DV9215TX,  
DV9216EA, DV9216TX, DV9217EA, DV9217TX, DV9218EA, DV9218TX, DV9219EA, DV9219TX, DV9220CA,  
DV9220EU, DV9220TX, DV9220US, DV9221EA, DV9221TX, DV9225US, DV9230US, DV9231CA, DV9232EU,  
DV9233CA, DV9233CL, DV9233EU, DV9235NR, DV9237EU, DV9241EA, DV9243EA, DV9244EA, DV9244EU,  
DV9248EA, DV9252EU, DV9253EA, DV9254EU, DV9255EA, DV9260NR, DV9260US, DV9265EA, DV9265LA,  
DV9266EA, DV9266EU, DV9267EA, DV9268EA, DV9269EA, DV9271EA, DV9272EA, DV9273EA, DV9274EU,  
DV9275EA, DV9275LA, DV9276EA, DV9283EA, DV9285EA, DV9286EA, DV9287CL, DV9288EA, DV9289EA,  
DV9291EA, DV9292EU, DV9293EA, DV9294EA, DV9294EU, DV9295EA, DV9295EU, DV9296EA, DV9296EU,  
DV9297EA, DV9299EA, DV9299XX, DV9300, DV9301TX, DV9302TX, DV9303EU, DV9303TX, DV9304EU, DV9304TX,  
DV9305EU, DV9306TX, DV9307TX, DV9308EA, DV9308NR, DV9308TX, DV9309EA, DV9309EU, DV9309TX,  
DV9310CA, DV9310EA, DV9310EU, DV9310TX, DV9310US, DV9311EA, DV9311EU, DV9311TX, DV9312EA,  
DV9312TX, DV9313EA, DV9314EA, DV9315CA, DV9315EA, DV9316EA, DV9317CA, DV9317CL, DV9317EA,  
DV9318CA, DV9318EA, DV9319EA, DV9320CA, DV9320EA, DV9320US, DV9321EA, DV9322EA, DV9324EA,  
DV9330CA, DV9330US, DV9331EU, DV9332EA, DV9332EU, DV9334US, DV9335NR, DV9337EU, DV9338EU,  
DV9339US, DV9340EA, DV9341EU, DV9342EU, DV9343CA, DV9343EU, DV9344EU, DV9345EU, DV9346EA,  
DV9347CL, DV9348EA, DV9350EA, DV9351EA, DV9361EA, DV9362EA, DV9363EA, DV9372EU, DV9374EU,  
DV9375EU, DV9377EA, DV9378EA, DV9379EA, DV9380CA, DV9380EA, DV9381EA, DV9385EA, DV9389EA,  
DV9390EA, DV9391EU, DV9392EA, DV9393EA, DV9394EA, DV9395EA, DV9396EA, DV9397EA, DV9398EA,  
DV9398EU, DV9399EA, DV9400, DV9401XX, DV9407NR, DV9408CA, DV9408NR, DV9410CA, DV9410US,  
DV9413CL, DV9417CA, DV9417CL, DV9418CA, DV9420CA, DV9420US, DV9428CA, DV9428NR, DV9429US,  
DV9438CA, DV9443CA, DV9500, DV9500EW, DV9501AU, DV9501XX, DV9502XX, DV9503AU, DV9505TX,  
DV9507TX, DV9508TX, DV9509TX, DV9511TX, DV9512TX, DV9513TX, DV9515CA, DV9515EF, DV9515EO,  
DV9516TX, DV9518EM, DV9518TX, DV9519TX, DV9520EB, DV9520TX, DV9521EJ, DV9521TX, DV9522TX,  
DV9525EN, DV9525EO, DV9525US, DV9530EB, DV9530EF, DV9530EM, DV9532EM, DV9533EF, DV9535NR,  
DV9535US, DV9540EB, DV9540US, DV9541EV, DV9542EV, DV9543CL, DV9543EV, DV9547CL, DV9548CA,  
DV9548US, DV9550EO, DV9550EP, DV9552ES, DV9555EG, DV9556EA, DV9560EG, DV9560ER, DV9562EZ,  
DV9565EG, DV9570EL, DV9570EO, DV9572EA, DV9574EA, DV9574LA, DV9575EF, DV9575EM, DV9575EN,  
DV9575EO, DV9575EP, DV9575ES, DV9575LA, DV9575NR, DV9576EA, DV9580EE, DV9580EG, DV9580EL,  
DV9580EN, DV9580EO, DV9580ET, DV9580EZ, DV9580US, DV9581EE, DV9585EG, DV9585EL, DV9588EF,  
DV9590EA, DV9590ED, DV9590EG, DV9590ER, DV9590ET, DV9590EZ, DV9592EF, DV9595EA, DV9595ED,  
DV9596XX, DV9597XX, DV9598XX, DV9599XX, DV9600, DV9601AU, DV9601TX, DV9602AU, DV9602TX, DV9603AU,  
DV9603TX, DV9604AU, DV9604TX, DV9605EF, DV9605EM, DV9605EO, DV9605TX, DV9606CA, DV9606TX,  
DV9607TX, DV9607US, DV9608CA, DV9608ES, DV9608NR, DV9608TX, DV9610CA, DV9610EB, DV9610EF,  
DV9610EM, DV9610ET, DV9610EV, DV9610TX, DV9610US, DV9611TX, DV9612CA, DV9612TX, DV9613TX,  
DV9614CA, DV9614TX, DV9615CA, DV9615TX, DV9616CA, DV9616TX, DV9617NR, DV9617TX, DV9618CA,  
DV9620EN, DV9620ET, DV9620US, DV9623CA, DV9623CL, DV9623ED, DV9625CA, DV9625ER, DV9625EW,  
DV9626US, DV9627CL, DV9628CA, DV9628NR, DV9629CA, DV9630EB, DV9630ED, DV9630EF, DV9630ET,  
DV9631EF, DV9631EM, DV9634CA, DV9635CA, DV9635EF, DV9635EM, DV9638US, DV9639EO, DV9640CA,  
DV9640US, DV9643EO, DV9644CA, DV9645ED, DV9645EF, DV9645EM, DV9645EO, DV9646EM, DV9647EF,  
DV9647EM, DV9649EF, DV9649EM, DV9650ES, DV9650US, DV9651XX, DV9652XX, DV9653CL, DV9655EA,  
DV9655EO, DV9655EZ, DV9657CL, DV9657EM, DV9657EO, DV9658EA, DV9660EB, DV9660EF, DV9660EG,  
DV9660EI, DV9660EV, DV9665EL, DV9665EO, DV9667EA, DV9670ED, DV9670EE, DV9670EF, DV9670EL,  
DV9670EM, DV9670EO, DV9675EG, DV9675EL, DV9675EO, DV9680ED, DV9680EF, DV9680EP, DV9680EV,  
DV9680EW, DV9680EZ, DV9681ER, DV9682EG, DV9684EG, DV9685EO, DV9686EO, DV9687EO, DV9688EG,  
DV9689EA, DV9690EE, DV9690EI, DV9690EL, DV9690EN, DV9690EV, DV9690EW, DV9690EZ, DV9691EG,  
DV9694EG, DV9695EA, DV9695EF, DV9695EG, DV9695EL, DV9695EO, DV9698EO, DV9699EF, DV9700, DV9700T,  
DV9700Z, DV9701AU, DV9701AX, DV9701TX, DV9701XX, DV9702AU, DV9702AX, DV9702TX, DV9702XX,  
DV9703AX, DV9703TX, DV9703XX, DV9704AX, DV9704TX, DV9705AX, DV9705TX, DV9706AX, DV9706TX,  
DV9711TX, DV9712TX, DV9714TX, DV9715NR, DV9715TX, DV9716TX, DV9717TX, DV9718TX, DV9719TX,

DV9720CA, DV9720TX, DV9720US, DV9723CA, DV9723CL, DV9724CA, DV9727CL, DV9727TX, DV9727US, DV9728CA, DV9728CL, DV9728TX, DV9729TX, DV9730CA, DV9730NR, DV9730TX, DV9730US, DV9731CA, DV9732TX, DV9733TX, DV9734NR, DV9735TX, DV9736CA, DV9736TX, DV9737TX, DV9738TX, DV9740CA, DV9740TX, DV9740US, DV9741TX, DV9742TX, DV9743CL, DV9743TX, DV9744CA, DV9744TX, DV9745TX, DV9746TX, DV9747CL, DV9747TX, DV9748CA, DV9750US, DV9751XX, DV9758CA, DV9770LA, DV9774CA, DV9775LA, DV9780LA, DV9785LA, DV9800, DV9803TX, DV9804CA, DV9808CA, DV9808TX, DV9809TX, DV9810CA, DV9810TX, DV9810US, DV9811TX, DV9812TX, DV9812US, DV9813TX, DV9814TX, DV9815NR, DV9815TX, DV9817CL, DV9818TX, DV9819TX, DV9819WM, DV9820TX, DV9820US, DV9821TX, DV9822TX, DV9823CA, DV9823CL, DV9823TX, DV9824CA, DV9825NR, DV9827CL, DV9830US, DV9831CA, DV9834CA, DV9838CA, DV9843CL, DV9847CA, DV9851XX, DV9854CA, DV9858CA, DV9894CA, DV9899XX, DV9900, DV9901TX, DV9903CA, DV9904CA, DV9907CA, DV9908CA, DV9910CA, DV9910US, DV9912NR, DV9913CL, DV9917CL, DV9920US, DV9922US, DV9924CA, DV9925NR, DV9927CL, DV9930US, DV9933CA, DV9933CL, DV9933NR, DV9934CA, DV9999US, TX1000, TX1100, TX1200, TX2600, V9500T, V9500Z, X1000, ZE2000, ZE2300, ZE2308, ZE2315, ZE4900, ZT3000, ZT3010, ZT3020, ZT4000, ZT4900,

#### Tablet PC Series

M2000, TC1000, TC1100, TC4200,

#### LG 19V4.74A 4.8mm\*1.7mm 90W

P300, R200, R405, R410, R500, R510, R700, S1,

#### HP 19.5V3.33A 4.8MM\*1.7MM 65W

#### HP

##### Envy series

13-2157NR, 4-1000, 4-1001TX, 4-1003TU, 4-1004TU, 4-1009TX, 4-1010TU, 4-1013TX, 4-1014TU, 4-1014TX, 4-1015TU, 4-1015TX, 4-1018TU, 4-1020TU, 4-1021TU, 4-1023TU, 4-1024TU, 4-1025T, 4-1025TU, 4-1026TU, 4-1028TU, 4-1029TU, 4-1030TX, 4-1031TU, 4-1032TX, 4-1033TX, 4-1034TX, 4-1035TX, 4-1045TU, 4-1048TU, 4-1050BR, 4-1050TU, 4-1051TU, 4-1051TX, 4-1052TU, 4-1052TX, 4-1053TU, 4-1053TX, 4-1054TU, 4-1054TX, 4-1056TX, 4-1057TX, 4-1060TX, 4-1061TX, 4-1102TX, 4-1103TU, 4-1103TX, 4-1104TU, 4-1104TX, 4-1105DX, 4-1105TU, 4-1105TX, 4-1106TU, 4-1106TX, 4-1107TU, 4-1108TU, 4-1109TU, 4-1109TX, 4-1110TU, 4-1110TX, 4-1110US, 4-1111TX, 4-1115DX, 4-1117NR, 4-1130US, 4-1150BR, 4-1150LA, 4-1152LA, 4-1155LA, 6-1000, 6-1001TU, 6-1001TX, 6-1002TU, 6-1003TU, 6-1003TX, 6-1004TX, 6-1005TU, 6-1005TX, 6-1006TU, 6-1007TU, 6-1007TX, 6-1008TX, 6-1009TX, 6-1010TU, 6-1010TX, 6-1011TU, 6-1011TX, 6-1012TU, 6-1013TU, 6-1013TX, 6-1014TU, 6-1014TX, 6-1015TU, 6-1015TX, 6-1016TU, 6-1016TX, 6-1017TU, 6-1017TX, 6-1018TU, 6-1018TX, 6-1019TU, 6-1019TX, 6-1021TU, 6-1022TU, 6-1022TX, 6-1023TX, 6-1024TX, 6-1025TU, 6-1025TX, 6-1026TU, 6-1101TU, 6-1102TU, 6-1110US, 6-1111NR, 6-1129WM, 6-1131NR, 6-1146NR,

##### Envy Sleekbook series

14-B000, 14-B000ED, 14-B000EE, 14-B000EI, 14-B000EO, 14-B000ET, 14-B001EA, 14-B001EIA, 14-B001TX, 14-B002TX, 14-B004TU, 14-B005AU, 14-B006AU, 14-B007AU, 14-B008AU, 14-B009AU, 14-B009TU, 14-B010AU, 14-B010US, 14-B012AU, 14-B013AU, 14-B014AU, 14-B014TU, 14-B015AU, 14-B015DX, 14-B022AU, 14-B023TX, 14-B024TU, 14-B025TU, 14-B028AU, 14-B028TU, 14-B030TU, 14-B031TU, 14-B034TU, 14-B035TU, 14-B038TU, 14-B043TU, 14-B062LA, 14Z-B000, 4-1005XX, 4-1007, 4-1008TX, 4-1010US, 4-1016NR, 4-1024, 4-1030TU, 4-1032TU, 4-1036TX, 4-1037TX, 4-1038TX, 4-1043CL, 4-1043TU, 4-1044TU, 4-1046TU, 4-1047TU, 4-1049TU, 4-1055TU, 4-1055TX, 4-1058TX, 4-1059TX, 4-1062TX, 4-1063TX, 4-1064TX, 4-1065TX, 4-1066TX, 4-1101TU, 4-1102TU, 4-1107TX, 4-1108TX, 4T-1000, 6-1000, 6-1000EV, 6-1000SV, 6-1002ET, 6-1002ST, 6-1004TX, 6-1005TU, 6-1005TX, 6-1005TX, 6-1006EA, 6-1006SA, 6-1010EB, 6-1010EO, 6-1010SO, 6-1010US, 6-1011ED, 6-1011NR, 6-1011SD, 6-1013TX, 6-1014NR, 6-1014TX, 6-1015NR, 6-1015TX, 6-1016T, 6-1017CL, 6-1019NR, 6-1020EV, 6-1020SV, 6-1020TU, 6-1021NR, 6-1023TU, 6-1024TU, 6-1031ER, 6-1040CA, 6-1047CL, 6-1048CA, 6-1050EX, 6-1050SX, 6-1054ER, 6-1058ER, 6-1071EF, 6-1071SF, 6-1080EX, 6-1080SX, 6-1083CA, 6-1090EE, 6-1101TX, 6-1102TX, 6-1103TX, 6-1140CA, 6-1168CA, 6-1180CA, 6T-1000, 6Z-1000,

##### Envy Spectre Series

13-2000, 13-2000EA, 13-2000EB, 13-2000ED, 13-2000EE, 13-2000EG, 13-2000EL, 13-2000EN, 13-2000EO,

13-2000ER, 13-2000ES, 13-2000ET, 13-2000EW, 13-2003EF, 13-2010EE, 13-2010EX, 13-2020EX, 13-2050NR, 13-2057NR, 13-2060EZ, 13-2090LA, 13-2095CA, 13-2150NR, 13T-2000, 14-3000, 14-3000EA, 14-3001TU, 14-3001XX, 14-3003TU, 14-3004TU, 14-3005TU, 14-3006TU, 14-3007TU, 14-3008TU, 14-3009TU, 14-3010NR, 14-3010TU, 14-3011TU, 14-3012TU, 14-3013TU, 14-3014TU, 14-3015TU, 14-3017NR, 14-3017TU, 14-3018TU, 14-3090CA, 14-3090LA, 14-3100EB, 14-3100ED, 14-3100EE, 14-3100EF, 14-3100EG, 14-3100EL, 14-3100EN, 14-3100EO, 14-3100ER, 14-3100ES, 14-3100ET, 14-3100EW, 14-3100EX, 14-3190LA, 14T-3100,

#### Envy Ultrabook series

13-1000, 13-1001TX, 13-1001XX, 13-1002TX, 13-1003XX, 13-1004TX, 13-1005TX, 13-1006TX, 13-1007EV, 13-1007LA, 13-1007TX, 13-1008TX, 13-1010ER, 13-1015ER, 13-1030CA, 13-1030NR, 13-1050EA, 13-1050EF, 13-1050EG, 13-1050ES, 13-1099EO, 13-1099XL, 13-1940EZ, 13T-1000, 4-1000, 4-1000ET, 4-1000SG, 4-1000ST, 4-1001ET, 4-1002TX, 4-1004TX, 4-1005XX, 4-1007TX, 4-1010EA, 4-1010ED, 4-1010EN, 4-1010EW, 4-1010SA, 4-1010SD, 4-1010SN, 4-1010SS, 4-1010SW, 4-1012TU, 4-1015DX, 4-1016TX, 4-1017NR, 4-1017TU, 4-1017TX, 4-1018TX, 4-1019TU, 4-1019WM, 4-1020EA, 4-1020EB, 4-1020ES, 4-1020EW, 4-1020SS, 4-1020SW, 4-1020TX, 4-1023TX, 4-1028TU, 4-1029TU, 4-1030CA, 4-1030ED, 4-1030EN, 4-1030SD, 4-1030SN, 4-1030SS, 4-1030US, 4-1031TU, 4-1031TX, 4-1035SG, 4-1035TU, 4-1035TX, 4-1038NR, 4-1038TU, 4-1038TX, 4-1040SS, 4-1040TU, 4-1041TX, 4-1043CL, 4-1043TX, 4-1044TX, 4-1045TU, 4-1045TX, 4-1046TX, 4-1048TX, 4-1049TX, 4-1050BR, 4-1050CA, 4-1050ER, 4-1050LA, 4-1050TX, 4-1051ER, 4-1051TU, 4-1051TX, 4-1052ER, 4-1052TX, 4-1053TU, 4-1053TX, 4-1054TX, 4-1056TX, 4-1057TX, 4-1060TX, 4-1061TX, 4-1062EF, 4-1062SF, 4-1062TX, 4-1066TX, 4-1070EF, 4-1070EL, 4-1070SF, 4-1080EO, 4-1080EX, 4-1080SX, 4-1090EO, 6T-1000,

HP 18.5V3.5A 4.8mm\*1.7mm 65W

#### Compaq

##### Armada series

100S, 110, 1100, 110S, E300, E500, E500S, E700, M300, M500, M700, V300,

##### Evo series

800C, 800V, 800W, N1000, N1000C, N1000V, N1005V, N110, N150, N200, N400, N400C, N410C, N600, N600C, N610, N610C, N610V, N620C, N800, N8000, N800C, N800V, N800W,

##### Presario series

1010 N, 1201VU, 1203VU, 1204VU, 1205VU, 1207VU, 1209VU, 1210VU, 1211VU, 1212VU, 1218TU, 1223TU, 1224TU, 1225TU, 1226TU, 1227TU, 1228TU, 1232TU, 1233TU, 1237TU, 1240TU, 1241TU, 1244TU, 1245TU, 1247TU, 1248TU, 1250TU, 1251TU, 1253TU, 1254TU, 1256TU, 1262TU, 1265TU, 1267TU, 1268TU, 1269TU, 1270TU, 1271TU, 1272TU, 1273TU, 1274TU, 1278TU, 1279TU, 1280TU, 1281TU, 1283TU, 1284TU, 1285TU, 1290TU, 1292TU, 1293TU, 1295TU, 1298TU, 1299TU, 1500, 1500SC, 1500US, 1501, 1502, 1502SC, 1503, 1505US, 1506, 1507, 1508, 1509, 1510, 1510US, 1511, 1512, 1516, 1520, 1520US, 1522, 1525, 1525US, 1531, 1535, 1538, 1550, 1555, 1568, 1570, 1572, 1580, 1814TU, 1822TU, 1823TU, 1825TU, 1826TU, 1827TU, 1901JP, 1902JP, 1903JP, 1928TU, 1929TU, 2018AL, 2021AL, 2023AL, 2024AP, 2029AP, 2037AP, 2038AP, 2200, 2200 N, 2200LA, 2201AP, 2201US, 2201XX, 2202XX, 2203AL, 2203AP, 2203AS, 2203US, 2204AL, 2204AP, 2204AS, 2204US, 2206AL, 2206AP, 2206US, 2208AP, 2208AS, 2209CL, 2210AP, 2210US, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2221AP, 2222AP, 2223US, 2224AP, 2225AP, 2226CL, 2227US, 2228AP, 2229AP, 2230AP, 2231AP, 2231US, 2232AP, 2232US, 2233AP, 2235AP, 2236AP, 2236CL, 2239AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2247AP, 2248AP, 2249AP, 2250AP, 2251AP, 2253AP, 2254AP, 2255AP, 2256AP, 2257AP, 2258AP, 2259AP, 2260AP, 2261AP, 2262AP, 2263AP, 2264AP, 2265AP, 2266AP, 2267AP, 2268AP, 2269AP, 2270AP, 2271AP, 2800, 2800CA, 2800T, 2800US, 2801CL, 2805US, 2817TX, 2818TX, 2819TX, 2820TX, 2830TX, 2831TX, 300, 620, 900, 900US, 905, 905US, 910, 910US, 912, 912RSH, 918, 918RSH, 920, 920US, A900, A909US, A910CA, A913CL, A916NR, A918CA, A924CA, A928CA, A930CA, A930XX, A931NR, A935TU, A936CA, A936TU, A938CA, A938TU, A939CA, A940CA, A940NR, A944CA, A945US, A948CA, A949NR, A966TU, A968TU, A969TU, A970TU, A971TU, B1011, B1013, B1014, B1015, B1015A, B1200, B1900, B2000, B2005AP, B2017AL, B3800, B3807AP, B3825AP, C300, C300EU, C301NR, C303NR, C304NR, C305LA, C306US, C307NR, C310EA, C310EU, C315LA, C318LA, C350EU, C399XX, C500, C500, C500EA, C500EU, C500T, C501NR, C501XX, C502CA, C502EA, C502EU, C502US, C502XX, C503WM, C504EA, C504EU, C504US, C506CA, C507TU, C507US, C508US, C509NR, C518LA, C540EA,



C542EA, C550, C550XX, C551NR, C551XX, C552CA, C552US, C552XX, C554US, C555NR, C556CA, C557CL, C559CL, C560US, C563NR, C564US, C567TU, C568LA, C568TU, C571NR, C581TU, C581WM, C700, C700LA, C700T, C700XX, C701LA, C701XX, C702LA, C702XX, C703LA, C705LA, C706NR, C707LA, C708LA, C709LA, C709TU, C710BR, C710TU, C711TU, C712NR, C713NR, C714NR, C715NR, C715TU, C717NR, C717TU, C718TU, C720BR, C720TU, C721TU, C725BR, C727US, C730BR, C730T, C730XX, C731XX, C732XX, C735TU, C737BR, C741TU, C743TU, C745TU, C746TU, C747TU, C748TU, C749TU, C750LA, C750T, C750TU, C751LA, C751NR, C753TU, C754CA, C756CA, C757CA, C757LA, C758CA, C758LA, C759LA, C760LA, C760T, C760XX, C761TU, C762NR, C763TU, C764NR, C766TU, C768CA, C768LA, C768TU, C769CA, C769US, C770US, C771US, C774TU, C775TU, C776CA, C776NR, C776TU, C777CL, C777NR, C777TU, C778TU, C779TU, C780TU, C781TU, C782TU, C792WU, C793WU, C795WU, C796TU, C796WU, C797TU, C798TU, C798VU, F500, F500EA, F500XX, F501XX, F502EA, F502LA, F504AU, F505AU, F505LA, F506LA, F545EA, F550, F552LA, F553CL, F553US, F555LA, F555US, F557US, F557WM, F558US, F560US, F560XX, F561XX, F562LA, F564LA, F565CA, F565LA, F566LA, F572US, F577CL, F579WM, F700, F700XX, F701XX, F702XX, F706LA, F712NR, F722CA, F730US, F731AU, F732AU, F732NR, F736AU, F737AU, F738AU, F739WM, F750CA, F750US, F754CA, F754LA, F755LA, F755US, F756CA, F756LA, F756NR, F759WM, F760XX, F761US, F761XX, F762NR, F763NR, F764AU, F764CA, F765CA, F767CL, F767NR, F768WM, F769CA, F769CL, F769WM, M2000, M2000Z, M2001XX, M2005US, M2007US, M2008AP, M2009AP, M2010US, M2011AP, M2013AP, M2015AP, M2015CL, M2015LA, M2017AP, M2025AP, M2026AP, M2027AP, M2031AP, M2036AP, M2048AP, M2051AP, M2055AP, M2056AP, M2057AP, M2058AP, M2059AP, M2099XX, M2101US, M2105US, M2108US, M2200, M2203AU, M2214LA, M2215EA, M2236AP, M2246AP, M2249AU, M2250AP, M2250AU, M2251AP, M2254AP, M2255AU, M2256AU, M2257AU, M2257TU, M2258AU, M2258TU, M2259AU, M2259TU, M2260AU, M2261TU, M2262AU, M2262TU, M2263AU, M2263TU, M2264AU, M2265TU, M2267TU, M2273TU, M2274TU, M2276TU, M2277TU, M2299XX, M2301NR, M2301XX, M2308EA, M2370EA, M2401EA, M2401XT, M2405LA, M2406EA, M2411EA, M2412EA, M2425LA, M2500 C, M2501TU, M2502AU, M2502TU, M2503AU, M2503TU, M2504AU, M2504TU, M2505AU, M2505TU, M2506AU, M2506TU, M2507TU, M2508AU, M2508TU, M2509AU, M2510AU, M2510TU, M2511AU, M2512TU, M2513AU, M2513TU, M2514AU, M2514TU, M2515LA, M2516TU, M2517TU, M2519TU, M2520TU, M2521TU, M2522TU, M2523TU, M2524TU, M2525TU, M2526TU, M2527TU, M2528TU, M2529TU, M2599XX, V1000, V1001AD, V1001AP, V1002AD, V1002AP, V1003AD, V1003AP, V1004, V1004AD, V1004AP, V1005AD, V1005AP, V1006AD, V1006AP, V1007AD, V1007AP, V1008AD, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, V1022AP, V1023AP, V1024AP, V1025AP, V1026AP, V1027AP, V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043XX, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1074AP, V1075AP, V1100, V1101AP, V1102AP, V1103AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1113AP, V1114AP, V1115AP, V1116AP, V1117AP, V1118AP, V1119AP, V1120AP, V1121AP, V1122AP, V1125AP, V1126AP, V1130AP, V1131AP, V1132AP, V1133AP, V1134AP, V2000, V2000T, V2000Z, V2001AP, V2001XX, V2002XX, V2009XX, V2010, V2010US, V2015AP, V2016AP, V2021AP, V2022AP, V2023AP, V2024AP, V2025AP, V2027AP, V2030, V2030AP, V2030US, V2031AP, V2032AP, V2033AP, V2034AP, V2037AP, V2038AP, V2040AP, V2041AP, V2042AP, V2043AP, V2044AP, V2045AP, V2046AP, V2069CL, V2100, V2105AP, V2107AP, V2110US, V2111AP, V2115AP, V2116AP, V2124AP, V2128AP, V2130AP, V2131AP, V2135US, V2136AP, V2140US, V2142AP, V2143AP, V2144AP, V2145AP, V2146CL, V2148AP, V2155AP, V2157AP, V2160AP, V2200, V2205US, V2208CL, V2210US, V2220US, V2300, V2304AP, V2304US, V2305AP, V2305US, V2306US, V2309US, V2310US, V2311US, V2312US, V2321US, V2330AP, V2335US, V2341AP, V2342AP, V2345AP, V2347AP, V2350AP, V2351AP, V2356AP, V2358AP, V2359AP, V2361AP, V2362TU, V2374AP, V2377TU, V2378TU, V2379TU, V2382TU, V2383TU, V2385TU, V2387TU, V2389TU, V2390TU, V2391TU, V2392TU, V2393TU, V2394TU, V2397TU, V2398TU, V2398XX, V2399TU, V2399XX, V2400, V2400AU, V2400TU, V2401CL, V2401TU, V2401XX, V2402US, V2403NR, V2403TU, V2404US, V2405AU, V2405TU, V2405US, V2406TU, V2408AU, V2410TU, V2410US, V2411TU, V2412TU, V2413US, V2414NR, V2415LA, V2415TU, V2416TU, V2417AU, V2417LA, V2418TU, V2421AU, V2422AU, V2423AU, V2424NR, V2427AU, V2428AU, V2429AU, V2430AU, V2434AU, V2436AU, V2500, V2508WM, V2552US, V2555US, V2565US, V2570CA, V2570NR, V2575CA, V2575US, V2582US, V2600, V2601TN, V2601TS, V2602XT, V2603TS, V2604TS, V2605LA, V2605TS, V2606AU, V2606CU, V2607CA, V2607CL, V2608AU, V2608CA, V2608WM, V2609AU, V2609TN, V2610AU, V2610CA, V2610TN, V2610TS, V2610US, V2611TN, V2612AU, V2612TN, V2613TN, V2614TN, V2615AU, V2615LA, V2615TN, V2615US, V2616AU, V2616TS, V2617LA, V2618AU, V2619AU, V2619TN, V2620TN, V2621AU, V2622AU, V2624AU, V2624TS, V2625TS, V2626TS, V2627TS, V2628AU, V2628TN, V2628TS, V2629TN, V2629TS, V2630AU, V2630CA, V2630TN, V2630US, V2631AU, V2631TS, V2634AU, V2634TS, V2635AU, V2635TS, V2636TS, V2637TS, V2638TS, V2639TS, V2644TS, V2645TS, V2646TS, V2650AU, V2650CA, V2652AU, V2653AU, V2655US, V2658US, V2660AU, V2663AU, V2664AU, V2665AU, V2665US, V2670CA, V2670US, V2674AU, V2675AU, V2698XX, V2699XX, V2710US, V2718LA, V2718WM, V2720NR, V2720WM, V2721NR, V3000, V3000T, V3000Z, V3001XX, V3002TU, V3002XX, V3003TU, V3003XX, V3004XX, V3006TU, V3008AU, V3009AU, V3010US, V3011XX, V3013AU, V3014AU, V3014TU, V3015NR, V3016US, V3017LA, V3018CL, V3018US, V3019TU, V3019US, V3020TU, V3020US, V3021TU, V3022TU, V3024AU, V3029TU, V3030TU, V3030US, V3031AU, V3031TU, V3032TU, V3036TU, V3038TU, V3042TU, V3043TU, V3044TU, V3047AU, V3048TU, V3049TU, V3051TU, V3052TU, V3053TU, V3055TU, V3071TU, V3072TU, V3100, V3101XX, V3102XX, V3103XX, V3104XX, V3110CA, V3114AU, V3115LA, V3115TU, V3116TU, V3117LA, V3124TU, V3126TU, V3131AU, V3139AU, V3140AU, V3144AU, V3147AU, V3156AU, V3156TU, V3157AU, V3168AU, V3182TU, V3183TU, V3200, V3218LA, V3230AU, V3231AU, V3241AU, V3241TU, V3242TU, V3245AU, V3247AU, V3254TU, V3255AU, V3255TU, V3257TU, V3258TU, V3300, V3301XX, V3302XX, V3311AU, V3312AU, V3315LA, V3317LA, V3336TU, V3337TU, V3338TU, V3339TU, V3340TU, V3341TU, V3342TU, V3350TU, V3400, V3401TU, V3401TX, V3402AU, V3402TX, V3403TX, V3405AU, V3406AU, V3406TX, V3408TX, V3409AU, V3411TX, V3413TX, V3415LA, V3415TU, V3416TX, V3417LA,

V3418LA, V3418TU, V3419TU, V3420AU, V3421AU, V3422AU, V3423AU, V3423TX, V3424TX, V3425TU, V3425TX, V3426AU, V3427AU, V3428TU, V3429AU, V3429TU, V3430AU, V3433AU, V3433TU, V3434AU, V3435AU, V3436TU, V3439AU, V3443TU, V3444AU, V3444TU, V3445AU, V3445TU, V3446AU, V3447AU, V3448AU, V3449AU, V3450AU, V3501XX, V3523TU, V3532TU, V3533TU, V3534TU, V3600 C, V3601AU, V3601TU, V3601XX, V3602AU, V3602TU, V3602XX, V3603TU, V3603TX, V3604AU, V3606TU, V3607TU, V3607TU, V3608TU, V3609AU, V3609TU, V3610AU, V3610TU, V3611TX, V3612AU, V3612TX, V3613AU, V3613TX, V3614TX, V3615TX, V3616TX, V3617LA, V3618LA, V3619LA, V3621AU, V3621TU, V3622TU, V3623TU, V3624TU, V3625TU, V3632AU, V3633AU, V3634AU, V3635AU, V3636AU, V3637AU, V3638AU, V3639AU, V3640AU, V3642AU, V3643AU, V3644AU, V3645AU, V3646AU, V3647AU, V3651AU, V3652AU, V3653AU, V3653TU, V3654TU, V3655TU, V3656TU, V3657TU, V3658TU, V3659TU, V3661TU, V3662TU, V3663TU, V3664TU, V3665TU, V3666TU, V3667TU, V3668TU, V3669TU, V3670TU, V3671TU, V3672TU, V3673TU, V3674TU, V3675TU, V3676TU, V3677TU, V3678TU, V3679TU, V3680TU, V3700 C, V3701AU, V3701TU, V3701VU, V3701XX, V3702TX, V3702VU, V3703TU, V3703TX, V3703VU, V3704AU, V3704TU, V3704VU, V3705AU, V3705TU, V3705VU, V3706AU, V3706TU, V3707AU, V3707TU, V3707TX, V3708AU, V3708TU, V3709AU, V3709TU, V3710AU, V3710TU, V3711AU, V3711TU, V3712TU, V3713AU, V3713TU, V3714AU, V3714TU, V3715AU, V3715LA, V3715TU, V3716AU, V3716TU, V3717LA, V3717TU, V3718LA, V3718TU, V3719AU, V3719TU, V3720AU, V3720TU, V3722AU, V3723AU, V3723TU, V3724AU, V3724TU, V3725TU, V3726AU, V3726TU, V3727TU, V3728TU, V3729TU, V3730AU, V3731TU, V3732TU, V3733TU, V3734TU, V3735TU, V3736AU, V3737AU, V3738AU, V3739AU, V3740AU, V3741AU, V3741TU, V3742AU, V3743AU, V3744TU, V3745AU, V3746AU, V3746TU, V3747AU, V3747TU, V3748TU, V3749TU, V3750AU, V3750TU, V3751TU, V3751XX, V3752TU, V3752XX, V3754TU, V3755AU, V3755TU, V3756TU, V3757TU, V3758TU, V3761TU, V3762TU, V3763TU, V3764TU, V3766TU, V3767TU, V3768TU, V3769TU, V3770TU, V3774TU, V3775TU, V3778TU, V3779TU, V3781TU, V3782TU, V3783TU, V3785TU, V3787TU, V3797TU, V3798TU, V3799TU, V3801AU, V3801TU, V3801TX, V3802TU, V3803TU, V3804TU, V3804TX, V3805TU, V3806TU, V3808TX, V3809TU, V3810TU, V3811TU, V3812TU, V3813AU, V3813TU, V3814AU, V3815AU, V3817AU, V3818AU, V3819TU, V3820AU, V3820TU, V3823AU, V3823TU, V3824AU, V3824TU, V3825AU, V3826AU, V3826TU, V3827TU, V3828TU, V3829TU, V3830TU, V3831TU, V3832TU, V3833TU, V3834TU, V3835TU, V3838TU, V3844TU, V3846TU, V3847TU, V3848TU, V3849TU, V3851XX, V3853TU, V3854TU, V3855TU, V3856TU, V3857TU, V3901TU, V3904TU, V3904TX, V3906AU, V3906TU, V3907AU, V3907TU, V3908TU, V3909TU, V3910TX, V3914TU, V3916TU, V3919TU, V3920TU, V3921TU, V3922TU, V3923TU, V3925TU, V3927TU, V3928TU, V3929TU, V3930TU, V3931TU, V3932TU, V4000, V4000T, V4000XX, V4002XX, V4003XX, V4004XX, V4005CL, V4005XX, V4015US, V4020US, V4025US, V4035CA, V4035US, V4100, V4101AP, V4103AP, V4114AP, V4118AP, V4120US, V4122TU, V4125CL, V4135US, V4200, V4201XX, V4202EA, V4202XX, V4203XX, V4205EA, V4209TU, V4212TU, V4214TU, V4216TU, V4217EA, V4217TU, V4218TU, V4219TU, V4220NR, V4220TU, V4222TU, V4223TU, V4225TU, V4227TU, V4228TU, V4230TU, V4232TU, V4233TU, V4240US, V4245US, V4275EA, V4305EA, V4308EA, V4310NR, V4320EA, V4322EA, V4325US, V4332EA, V4332US, V4333EA, V4335EA, V4336EA, V4338EA, V4347EA, V4354EA, V4376EA, V4377EA, V4382EA, V4387EA, V4400, V4401TU, V4402XX, V4403TU, V4404TU, V4405TU, V4406TU, V4407TU, V4408TU, V4435NR, V4440US, V4450EA, V5000, V5000T, V5002EA, V5004EA, V5005US, V5006EA, V5009EA, V5015US, V5025EA, V5026EA, V5030EA, V5031EA, V5032EA, V5033EA, V5054EA, V5059EA, V5079EA, V5088XX, V5094EA, V5099EA, V5099XX, V5100, V5101TU, V5101US, V5102NR, V5103AU, V5103TU, V5104AU, V5104TU, V5105CA, V5105EU, V5105TU, V5105US, V5106EU, V5106TU, V5107TU, V5108CU, V5108TU, V5109TU, V5110EU, V5110TU, V5111EU, V5111TU, V5115CA, V5115EU, V5115US, V5119US, V5120EU, V5120NR, V5125EU, V5150EA, V5160EA, V5160US, V5162EA, V5189XX, V5199XX, V5200, V5201CA, V5201US, V5203TU, V5204NR, V5204TU, V5204US, V5205NR, V5205TU, V5206OM, V5206TU, V5207NR, V5209US, V5210TU, V5210US, V5211TU, V5213TU, V5215LA, V5215TU, V5218LA, V5218TU, V5219TU, V5220TU, V5221EA, V5221TU, V5222TU, V5223TU, V5224TU, V5225TU, V5226TU, V5228TU, V5229TU, V5230TU, V5231TU, V5232EA, V5239TU, V5243TU, V5299XX, V5300, V5303NR, V5304US, V5306US, V5307US, V5310US, V5315WM, V6000, V6000T, V6000TX, V6000Z, V6001XX, V6002XX, V6003AU, V6012EA, V6016EA, V6048CL, V6057EA, V6100, V6101AU, V6101US, V6101XX, V6102EA, V6102XX, V6103NR, V6104NR, V6104US, V6105EA, V6105NR, V6106TU, V6107US, V6108EA, V6109AU, V6109EA, V6109EU, V6109OM, V6110CA, V6110EA, V6110US, V6112EU, V6113EA, V6115EA, V6115EU, V6115OM, V6117EU, V6120CA, V6120US, V6125TU, V6126EU, V6127EA, V6127TU, V6128EA, V6128EU, V6129EA, V6130US, V6131EU, V6133CA, V6133CL, V6133EU, V6137EU, V6137US, V6138EU, V6139EU, V6140TU, V6141TU, V6143CL, V6144EA, V6145EA, V6147EA, V6148EA, V6149EA, V6150EA, V6151EA, V6151TU, V6152EA, V6155EA, V6171CL, V6180EA, V6181EA, V6182EA, V6198XX, V6199XX, V6200, V6200XX, V6202EA, V6203TU, V6204EA, V6205NR, V6206AU, V6210BR, V6210CA, V6210US, V6212EA, V6213AU, V6213EA, V6215BR, V6215CA, V6216CA, V6216EA, V6217EA, V6218EA, V6220BR, V6223EA, V6223EU, V6224EA, V6225BR, V6230BR, V6230CA, V6233EU, V6254EA, V6261EU, V6263EA, V6264EA, V6272EU, V6299XX, V6300, V6301AU, V6304AU, V6304TU, V6305CA, V6305NR, V6310CA, V6310US, V6313TU, V6316CA, V6317CA, V6318CA, V6318TU, V6319TU, V6320CA, V6399XX, V6400, V6401AU, V6401XX, V6402CA, V6403AU, V6403TU, V6405CA, V6407TU, V6408TU, V6410CA, V6410TU, V6411TU, V6415CA, V6420US, V6421TU, V6422TU, V6423TU, V6428TU, V6444US, V6498XX, V6499XX, V6500, V6500T, V6500Z, V6501AU, V6501XX, V6502AU, V6507AU, V6511TU, V6512TU, V6513TU, V6514TU, V6515TU, V6599XX, V6600, V6601AU, V6604TU, V6605TU, V6606TU, V6607TU, V6608TU, V6609AU, V6609TU, V6611AU, V6611TU, V6612AU, V6612TU, V6613TU, V6614TU, V6615TU, V6616AU, V6616TU, V6617AU, V6618AU, V6620US, V6700, V6700TX, V6701XX, V6702AU, V6702TU, V6703AU, V6703TU, V6703XX, V6705TU, V6706TU, V6707TU, V6709TU, V6710TU, V6710XX, V6711TU, V6712TU, V6713TU, V6714TU, V6715TU, V6719NR, V6741US, V6751XX, V6801AU, V6802TU, V6803TU, V6804TU, V6805TU, V6806TU, V6807TU, V6808TU, V6808TX, V6899XX, V6900, V6903TU, V6904TU, V6905TU, X1000, X1001US, X1002US, X1005EA, X1006EA, X1007EA, X1010AL, X1010CA, X1010EA, X1010US, X1011AL, X1012AL, X1012EA, X1012QV, X1015, X1015US, X1016EA, X1018CL, X1020EA, X1020US, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1028CL, X1029AP, X1030, X1030AP, X1030US, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040, X1040AP, X1040US, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, X1047AP, X1048AP, X1049AP,

X1050AP, X1050US, X1051AP, X1052AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1058CL, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1105EA, X1110EA, X1115EA, X1140EA, X1155EA, X1200, X1201AP, X1201US, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1210CA, X1210US, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1220EA, X1220US, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1230US, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1301US, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1326AP, X1327AP, X1328AP, X1329AP, X1330AP, X1360US, X1370US, X1390, X1390US, X1397, X1400, X1401US, X1402AP, X1402US, X1403AP, X1405AP, X1406AP, X1408AP, X1410AP, X1415AP, X1416AP, X1422AP, X1429AP, X1430AP, X1431AP, X1432AP, X1435AP, X1436AP, X1437AP, X1441AP, X1442AP, X1460US, X1480, X1480US, X1500, X1560CA,

#### Prosignia series

160, 165, 170, 190, 800,

#### HP

##### Business Notebook series

510, 530, 550, 6720, 6720S, 6720T, G5000, G6000, NC4000, NC4010, NC4200, NC4300, NC6000, NC6100, NC6105, NC6110, NC6115, NC6120, NC6220, NC6230, NC7200, NC8000, NC8230, NW8000, NX4800, NX4820, NX5000, NX5100, NX6100, NX6105, NX6110, NX6115, NX6120, NX6125, NX6130, NX6330, NX7000, NX7010, NX7040, NX7100, NX7200, NX7220, NX8000, NX9000, NX9020, NX9030, NX9040, NX9050,

#### Folio series

13, 13-1000,

#### Mini series

311-1000, 311-1000NR, 311-1001XX, 311-1021NR, 311-1022NR, 311-1025NR, 311-1025TU, 311-1028TU, 311-1036TU, 311-1037NR, 311-1037TU, 311-1038NR, 311-1100, 311-1109TU, 311-1110TU,

#### Notebook PC series

510, 520, 530, 540, 541, 550,

#### Pavilion series

DV1000, DV1000-DZ677AV, DV1000-DZ678AV, DV1000-DZ731AV, DV1000T, DV1001AP, DV1001AP-PK809AS, DV1001XX, DV1001XX-PK807AS, DV1002AP-PF352PA, DV1002XX, DV1002XX-PK808AS, DV1003AP-PF353PA, DV1004AP-PF354PA, DV1005AP-PF355PA, DV1006AP-PF356PA, DV1007AP, DV1007AP-PF367PA, DV1008AP, DV1008AP-PF368PA, DV1009AP-PH468PA, DV1009XX, DV1009XX-PR284AS, DV1010, DV1010AP-PH476PA, DV1010CA, DV1010CA-PM056UA, DV1010CA-PM056UAR, DV1010US, DV1010US-PM053UAR, DV1011AP, DV1012AP-PD111PA, DV1012LA, DV1012LA-PQ641LA, DV1013AP-PD110PA, DV1013AP-PD112PA, DV1014AP-PD113PA, DV1014LA-PP888LA, DV1015AP-PD114PA, DV1015LA-PN713LA, DV1016AP-PD117PA, DV1017AP, DV1017AP-PD118PA, DV1018AP, DV1018AP-PD119PA, DV1019AP-PD120PA, DV1010US-PM053UA, DV1020AP-PH482PA, DV1021AP, DV1021AP-PH483PA, DV1022AP, DV1022AP-PN562PA, DV1023AP-PN563PA, DV1024AP, DV1024AP-PN575PA, DV1024LA-PP889LA, DV1025AP, DV1025AP-PN576PA, DV1025LA, DV1025LA-PN712LA, DV1026AP, DV1026AP-PN907PA, DV1027AP, DV1027AP-PN578PA, DV1029AP-PN888PA, DV1029AP-PN908PA, DV1030, DV1030AP-PN910PA, DV1031AP-PP963PA, DV1032AP, DV1032AP-PP971PA, DV1033AP, DV1033AP-PP981PA, DV1034AP, DV1034AP-P982PA, DV1035AP, DV1035AP-PP989PA, DV1036AP, DV1036AP-PS939PA, DV1037AP-PS940PA, DV1040CA, DV1040CA-PM057UA, DV1040CA-PM057UAR, DV1040US, DV1040US-PM054UA, DV1040US-PM054UAR, DV1042QV, DV1042QV-PM055UA, DV1044LA-PP890LA, DV1049CL, DV1049CL-PM058UA, DV1049CL-PM058UAR, DV1060US, DV1060US-PM059UA, DV1060US-PM059UAR, DV1065US, DV1065US-PM061UA, DV1065US-PM061UAR, DV1067EA-PQ563EA, DV1068EA-PQ564EA,

DV1071EA-PQ562EA, DV1100, DV1101AP-PS925PA, DV1102AP-PS926PA, DV1115LA, DV1117LA, DV1118AP, DV1120AP, DV1120US, DV1122AP, DV1122AP-PV253PA, DV1125AP, DV1125LA, DV1126AP, DV1127AP, DV1128AP-PV295PA, DV1130US, DV1133WM, DV1134AP, DV1135AP, DV1135LA, DV1139AP, DV1150US, DV1156CL, DV1170US, DV1175US, DV1180US, DV1200, DV1206CL, DV1207US, DV1210US, DV1215WM, DV1217US, DV1220US, DV1227US, DV1240CA, DV1240US, DV1245CL, DV1300, DV1300-DT111AV, DV1301AP, DV1301XX, DV1302AP, DV1302XX, DV1303AP, DV1304AP, DV1306AP, DV1307AP, DV1309AP, DV1310AP, DV1310US, DV1311SE, DV1312AP, DV1315CL, DV1316AP, DV1317AP, DV1317LA, DV1318AP, DV1319AP, DV1320AP, DV1320US, DV1321AP, DV1321US, DV1322AP, DV1323AP, DV1324AP, DV1326AP, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1330CA, DV1330US, DV1331SE, DV1332AP, DV1334AP, DV1336AP, DV1340AP, DV1340US, DV1344AP, DV1345AP, DV1346AP, DV1347AP, DV1348AP, DV1353AP, DV1354AP, DV1355AP, DV1356AP, DV1357AP, DV1358AP, DV1359AP, DV1360AP, DV1361AP, DV1362AP, DV1363AP, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375TU, DV1376TU, DV1377TU, DV1378TU, DV1380TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1390TU, DV1391TU, DV1392TU, DV1395TU, DV1396TU, DV1399XX, DV1400, DV1410US, DV1411SE, DV1420US, DV1421EA, DV1427US, DV1430US, DV1432US, DV1439US, DV1440CA, DV1440US, DV1500, DV1501EA, DV1510CA, DV1510US, DV1515CL, DV1519US, DV1520US, DV1530BR, DV1530CA, DV1530LA, DV1530US, DV1532US, DV1534EA, DV1535EA, DV1535LA, DV1536EA, DV1540CA, DV1540LA, DV1540US, DV1546EA, DV1547EA, DV1550SE, DV1552EA, DV1555EA, DV1580SE, DV1586EA, DV1588EA, DV1589EA, DV1591EA, DV1594EA, DV1595EA, DV1596EA, DV1597EA, DV1598EA, DV1599EA, DV1600, DV1601TN, DV1602TN, DV1605TN, DV1606TS, DV1607TS, DV1608TS, DV1609TS, DV1610US, DV1612TS, DV1614TS, DV1618EA, DV1619EA, DV1620EA, DV1620US, DV1621EA, DV1621TN, DV1621TS, DV1622EA, DV1622NR, DV1623EA, DV1624NR, DV1624TS, DV1625LA, DV1626TN, DV1627TN, DV1629US, DV1633TN, DV1634TN, DV1635CA, DV1635LA, DV1635TN, DV1636TN, DV1648US, DV1650CA, DV1650US, DV1656US, DV1657CL, DV1657EA, DV1658EA, DV1658US, DV1659EA, DV1659US, DV1660CA, DV1660SE, DV1664EA, DV1665EA, DV1666EA, DV1668EA, DV1669EA, DV1670EA, DV1670US, DV1674EA, DV1675EA, DV1677EA, DV1679EA, DV1680CA, DV1680EA, DV1680US, DV1688US, DV1693EA, DV1694EA, DV1695EA, DV1699XX, DV1700, DV1700TU, DV1701TU, DV1701XX, DV1702XX, DV1703TU, DV1703XX, DV1704XX, DV1705TU, DV1706TU, DV1707TU, DV1708NR, DV1709TU, DV1710TU, DV1710US, DV1712US, DV1712US, DV1714TU, DV1715TU, DV1716TU, DV1720LA, DV1721LA, DV1721TU, DV1722TU, DV1725TU, DV1727TU, DV1730LA, DV1731TU, DV1738OD, DV1740BR, DV1740TU, DV1744TU, DV1750BR, DV1760BR, DV2000, DV2000T, DV2000Z, DV2001TU, DV2001TX, DV2001XX, DV2002TU, DV2002TX, DV2002XX, DV2003EA, DV2003TU, DV2003TX, DV2004EA, DV2004TU, DV2004TX, DV2004XX, DV2005EA, DV2005TU, DV2005TX, DV2005XX, DV2006EA, DV2006TU, DV2006TX, DV2006XX, DV2007EA, DV2007TU, DV2007TX, DV2008EA, DV2008TU, DV2008TX, DV2009EA, DV2009TU, DV2009TX, DV2009XX, DV2010EA, DV2010TU, DV2010TX, DV2011EA, DV2011TU, DV2011TX, DV2011XX, DV2012EA, DV2012TU, DV2012TX, DV2013EA, DV2013TU, DV2013TX, DV2014EA, DV2014TU, DV2014TX, DV2015EA, DV2015NR, DV2015TU, DV2015TX, DV2016EA, DV2016TU, DV2016TX, DV2017EA, DV2017TU, DV2017TX, DV2018EA, DV2018TU, DV2018TX, DV2019EA, DV2019TU, DV2019TX, DV2020CA, DV2020EA, DV2020TU, DV2020TX, DV2020US, DV2021TU, DV2021TX, DV2022TU, DV2022US, DV2023TU, DV2024TU, DV2024TX, DV2025LA, DV2025NR, DV2025TU, DV2025TX, DV2026TU, DV2026TX, DV2027TU, DV2027TX, DV2028EA, DV2028TU, DV2028TX, DV2029EA, DV2029TU, DV2029TX, DV2030EA, DV2030TU, DV2030TX, DV2031EA, DV2031TU, DV2031TX, DV2032EA, DV2032TU, DV2032TX, DV2033EA, DV2033TU, DV2033TX, DV2034EA, DV2034TU, DV2034TX, DV2035EA, DV2035LA, DV2035TU, DV2035TX, DV2035US, DV2036EA, DV2036TU, DV2036TX, DV2037TU, DV2037TX, DV2037US, DV2038TU, DV2038TX, DV2039TU, DV2039TX, DV2040CA, DV2040TU, DV2040TX, DV2040US, DV2041TU, DV2041TX, DV2042TU, DV2042TX, DV2043TU, DV2043TX, DV2044TU, DV2044TX, DV2045EA, DV2045TU, DV2046TU, DV2046TX, DV2047CL, DV2047TU, DV2047TX, DV2048TX, DV2049TX, DV2050TU, DV2050TX, DV2050US, DV2053EA, DV2054EA, DV2055EA, DV2056EA, DV2057EA, DV2058EA, DV2064EA, DV2065EA, DV2080EA, DV2081EA, DV2082EA, DV2083EA, DV2084EA, DV2085EA, DV2088XX, DV2095EA, DV2097EA, DV2098EA, DV2099EA, DV2100, DV2101EU, DV2101XX, DV2102XX, DV2103EA, DV2103TU, DV2103XX, DV2104EA, DV2104EU, DV2104NR, DV2104TU, DV2104XX, DV2105EA, DV2105XX, DV2106EA, DV2106EU, DV2108EA, DV2109NR, DV2110EU, DV2110RS, DV2111RS, DV2112RS, DV2115EA, DV2115WM, DV2116, DV2116EA, DV2116TX, DV2116WM, DV2119XX, DV2120, DV2120CA, DV2120LA, DV2120TU, DV2120US, DV2123EU, DV2123TU, DV2125, DV2125EA, DV2125LA, DV2125NR, DV2126EA, DV2129EA, DV2129TX, DV2129US, DV2130, DV2130EA, DV2130TX, DV2130US, DV2131EA, DV2133EA, DV2134EA, DV2134US, DV2135BR, DV2135LA, DV2138XX, DV2140BR, DV2140EU, DV2140TX, DV2141EU, DV2142TX, DV2143TX, DV2145BR, DV2147EA, DV2149EA, DV2150EA, DV2150TX, DV2151TX, DV2152EA, DV2152TX, DV2164EU, DV2166EU, DV2171, DV2171CA, DV2171CL, DV2171EA, DV2172EA, DV2173EA, DV2174, DV2174CL, DV2174EA, DV2175EA, DV2184EA, DV2185EA, DV2190EA, DV2195EU, DV2196EA, DV2197EA, DV2200, DV2200EA, DV2201CA, DV2201XX, DV2202CA, DV2202XX, DV2205EA, DV2207EA, DV2208EA, DV2209EA, DV2209TU, DV2210TU, DV2210US, DV2213CA, DV2213CL, DV2214US, DV2215EA, DV2215TU, DV2216EA, DV2217EA, DV2220US, DV2221US, DV2222EA, DV2222LA, DV2224EA, DV2225NR, DV2227EA, DV2240BR, DV2244EA, DV2245BR, DV2245EA, DV2246EA, DV2247BR, DV2250BR, DV2255BR, DV2260BR, DV2265EA, DV2267EA, DV2268EA, DV2275EA, DV2276EA, DV2278EA, DV2281EA, DV2282EA, DV2297EA, DV2298EA, DV2300, DV2301AU, DV2302AU, DV2303AU, DV2304AU, DV2305AU, DV2306AU, DV2308TU, DV2310CA, DV2310US, DV2312US, DV2313CA, DV2313CL, DV2315NR, DV2315US, DV2317CA, DV2320LA, DV2320US, DV2322LA, DV2325LA, DV2400, DV2401XX, DV2402CA, DV2402TX, DV2402XX, DV2404CA, DV2406TX, DV2407TX, DV2408CA, DV2409TX, DV2410CA, DV2410TX, DV2410US, DV2411TX, DV2412CA, DV2413CA, DV2413CL, DV2414TX, DV2415NR, DV2415TX, DV2415US, DV2416US, DV2418CA, DV2418NR, DV2419US, DV2420LA, DV2420US, DV2422CA, DV2422LA, DV2423LA, DV2425LA, DV2432CA, DV2432NR, DV2500, DV2500T, DV2500TV, DV2500TW, DV2500TX, DV2501XX, DV2502XX, DV2503XX, DV2504XX, DV2505XX, DV2506XX, DV2515TX, DV2525TX, DV2526TX, DV2527TX, DV2528TX,

DV2535LA, DV2535TX, DV2539TX, DV2550SE, DV2600, DV2601XX, DV2602CA, DV2602TU, DV2602TX, DV2602XX, DV2604TX, DV2605TX, DV2606TU, DV2606TX, DV2607TU, DV2608CA, DV2608TU, DV2609TU, DV2610CA, DV2610TU, DV2610US, DV2611TU, DV2612CA, DV2612TU, DV2613CL, DV2613TU, DV2613TX, DV2615NR, DV2615US, DV2617US, DV2618CA, DV2619NR, DV2620CA, DV2620US, DV2621LA, DV2622CA, DV2622LA, DV2624LA, DV2625LA, DV2626LA, DV2628TX, DV2629TX, DV2630TX, DV2631TX, DV2633TX, DV2634TX, DV2635LA, DV2635TX, DV2636TX, DV2638TX, DV2639TX, DV2640TX, DV2641TX, DV2642TX, DV2643TX, DV2644TX, DV2660SE, DV2700, DV2700TV, DV2700TW, DV2701XX, DV2702TU, DV2702TX, DV2702XX, DV2703TX, DV2703XX, DV2704TX, DV2704XX, DV2705TU, DV2705TX, DV2706TU, DV2706TX, DV2707TU, DV2707TX, DV2708CA, DV2708TU, DV2708TX, DV2709TU, DV2709TX, DV2710CA, DV2710TU, DV2710TX, DV2712TU, DV2712TX, DV2713CA, DV2713TX, DV2714CA, DV2714TU, DV2714TX, DV2715CA, DV2715NR, DV2715TX, DV2716CA, DV2716TX, DV2717TX, DV2718CA, DV2718TX, DV2718US, DV2719NR, DV2719TX, DV2720TX, DV2721TX, DV2722TX, DV2724CA, DV2725LA, DV2726CA, DV2726LA, DV2727CA, DV2728CA, DV2730TX, DV2734TX, DV2735TX, DV2736TX, DV2736US, DV2737TX, DV2738TX, DV2739TX, DV2740SE, DV2740TX, DV2741TX, DV2742SE, DV2745SE, DV2746TX, DV2747TX, DV2748TX, DV2749TX, DV2750TX, DV2751TX, DV2751XX, DV2752TX, DV2752XX, DV2755TX, DV2757TX, DV2759TX, DV2763TX, DV2765TX, DV2766TX, DV2768TX, DV2769TX, DV2770TX, DV2771TX, DV2774TX, DV2779TX, DV2781TX, DV2800T, DV2800TY, DV2801AU, DV2801TU, DV2801TX, DV2801XX, DV2802AU, DV2802TX, DV2803TU, DV2804CA, DV2804TU, DV2805, DV2805TU, DV2806TU, DV2807NR, DV2807TU, DV2808CA, DV2808TU, DV2809TU, DV2809TX, DV2810CA, DV2810TU, DV2810TX, DV2811TX, DV2812TX, DV2813TX, DV2814CA, DV2814TX, DV2815NR, DV2816TX, DV2817CA, DV2818CA, DV2818TX, DV2819NR, DV2820TX, DV2821TX, DV2823CA, DV2823TX, DV2824TX, DV2825TX, DV2826TX, DV2828CA, DV2829TX, DV2830TX, DV2831TX, DV2832TX, DV2833TX, DV2834CA, DV2834TX, DV2835TX, DV2836TX, DV2837TX, DV2838TX, DV2839TX, DV2840SE, DV2840TX, DV2841TX, DV2842SE, DV2842TX, DV2845SE, DV2846TX, DV2847TX, DV2848TX, DV2849TX, DV2850TX, DV2851XX, DV2854CA, DV2872LA, DV2890CA, DV2890NR, DV2894CA, DV2901TU, DV2901TX, DV2902TU, DV2902TX, DV2903TU, DV2904TU, DV2904TX, DV2905TU, DV2906TU, DV2907TU, DV2909TX, DV2910CA, DV2911TX, DV2911US, DV2914CA, DV2915CA, DV2915NR, DV2915TX, DV2917CA, DV2917CL, DV2917TX, DV2919TX, DV2920TX, DV2921TX, DV2925LA, DV2928CA, DV2928SE, DV2940SE, DV2941SE, DV2945SE, DV2946NR, DV2949SE, DV2988NR, DV2988SE, DV2990NR, DV2998NR, DV2999NR, DV4-2173NR, DV4000, DV4000-PC253AV, DV4000-PC268AV, DV4000-PC269AV, DV4000-PH856AV, DV4000-PH857AV, DV4000-PR496AV, DV4000LA, DV4000XX, DV4000XX-PX249AS, DV4001AP-PV281PA, DV4001EA-EB916EA, DV4001XX, DV4001XX-PX248AS, DV4002AP-PV282PA, DV4003AP-PV294PA, DV4004AP-PV298PA, DV4004XX, DV4004XX-PX251AS, DV4005AP-PV302PA, DV4005US, DV4005US-EA410UA, DV4005XX, DV4006AP-PV303PA, DV4006XX, DV4006XX-PX250AS, DV4007AP, DV4007AP-PV304PA, DV4007XX, DV4007XX-PX259AS, DV4008AP-PV316PA, DV4009AP-PV317PA, DV4010AP-PV318PA, DV4011AP-PV319PA, DV4012AP-PV320PA, DV4013AP-PV321PA, DV4014AP, DV4014AP-PV332PA, DV4014EA-EA037EA, DV4015AP-PV333PA, DV4015CL, DV4015CL-PX306UA, DV4015EA-EA034EA, DV4016AP-PY843PA, DV4016EA-EB907EA, DV4017AP, DV4017AP-PY853PA, DV4017EA-EA032EA, DV4018AP, DV4018AP-PY854PA, DV4018CL, DV4018EA-EB915EA, DV4019AP-PY881PA, DV4019EA-EA033EA, DV4020AP-PY882PA, DV4020EA-EA022EA, DV4020US-PX304UA, DV4021AP-PY883PA, DV4021EA, DV4021EA-EB923EA, DV4022AP, DV4022AP-ED099PA, DV4022EA-EB926EA, DV4023AP-ED100PA, DV4023EA-EB917EA, DV4024AP, DV4024AP-ED102PA, DV4024EA-EB924EA, DV4025AP-EE547PA, DV4025EA-EA036EA, DV4026AP-EE548PA, DV4027EA-EA038EA, DV4030CA, DV4030CA-PX311UA, DV4030EA, DV4030EA-EA021EA, DV4030EA-EB914EA, DV4030US, DV4030US-PX302UA, DV4031EA-EB910EA, DV4040CA, DV4040CA-PX308UA, DV4040EA-EB920EA, DV4040US, DV4040US-PX303UA, DV4043EA-EA030EA, DV4043EA-EB912EA, DV4045EA, DV4045EA-EA027EA, DV4045EA-EB919EA, DV4046EA-EA028EA, DV4049EA-EB921EA, DV4050EA-EA025EA, DV4051EA-EB918EA, DV4052EA-EB911EA, DV4054EA-EB913EA, DV4056EA-EA039EA, DV4057EA-EA029EA, DV4060EA-EA023EA, DV4070EA, DV4070EA-EB925EA, DV4073EA-EB908EA, DV4075EA-EA024EA, DV4078EA-EA026EA, DV4080EA-EB922EA, DV4085EA-EA031EA, DV4086EA-EA035EA, DV4100, DV4100-EA292AV, DV4100-EA294AV, DV4101AP, DV4101AP-PY885PA, DV4102AP, DV4102AP-PY896PA, DV4102EA-EH187EA, DV4103AP-PY905PA, DV4103EA-EF177EA, DV4104AP-PY906PA, DV4105AP-PY907PA, DV4106AP-ED098PA, DV4107AP-ED144PA, DV4108AP-ED145PA, DV4108EA-EF175EA, DV4109AP-ED146PA, DV4109EA-EH197EA, DV4110AP, DV4110AP-ED142PA, DV4110EA-EH725EA, DV4111AP, DV4111AP-ED143PA, DV4112AP-ED147PA, DV4113AP-ED148PA, DV4113EA-EH726EA, DV4114AP, DV4114AP-ED149PA, DV4115AP, DV4115AP-ED150PA, DV4115EA-EF190EA, DV4116AP-ED171PA, DV4117AP, DV4117AP-ED172PA, DV4118AP-ED174PA, DV4119AP-EE452PA, DV4120AP-EE483PA, DV4121AP, DV4121AP-EE501PA, DV4122AP-EE500PA, DV4122EA-EF186EA, DV4123AP-EE517PA, DV4124AP-EE518PA, DV4125AP, DV4125AP-EE524PA, DV4125EA-EH185EA, DV4125US, DV4125US-EC325UA, DV4126AP-EE528PA, DV4126EA-EH183EA, DV4127AP-EE529PA, DV4128AP, DV4128AP-EE553PA, DV4128EA-EH191EA, DV4129AP, DV4129AP-EH019PA, DV4129EA-EH730EA, DV4129US, DV4130AP, DV4130AP-EH020PA, DV4130EA, DV4130EA-EF171EA, DV4130US, DV4130US-EC317UA, DV4131EA-EF182EA, DV4134EA-EH180EA, DV4135EA-EH724EA, DV4136EA-EF183EA, DV4137EA-EH192EA, DV4138EA-EF188EA, DV4139EA-EK552EA, DV4140EA-EF178EA, DV4141EA-EH731EA, DV4142EA-EH188EA, DV4143EA-EF179EA, DV4144EA-EK553EA, DV4145EA-EF176EA, DV4146EA-EH182EA, DV4146EA-EH727EA, DV4148EA-EK551EA, DV4149EA-EH181EA, DV4150CA-EC322UA, DV4150EA, DV4150EA-EF172EA, DV4150US, DV4150US-EC316UA, DV4151EA-EF185EA, DV4152EA-EH173EA, DV4152EA-EH196EA, DV4153EA-EH178EA, DV4154EA-EH179EA, DV4155CL, DV4155CL-EC321UA, DV4155EA-EH186EA, DV4155US, DV4155US-EC324UA, DV4156EA-EH194EA, DV4157EA-EH732EA, DV4158EA-EF184EA, DV4159EA-EH729EA, DV4160EA-EH728EA, DV4161EA-EF180EA, DV4162EA-EH189EA, DV4163EA-EF174EA, DV4164EA-EH184EA, DV4165CL, DV4165CL-EC318UA, DV4165EA-EF187EA, DV4170CA-EC320UA, DV4170US, DV4170US-EC315UA, DV4174EA-EH733EA, DV4176EA-EH190EA, DV4178EA-EF189EA, DV4180US-EC327UA, DV4182EA-EH195EA, DV4199EA-EF181EA,

DV4200, DV4201TU, DV4201TX, DV4201XX, DV4202TU, DV4202XX, DV4203EA-EK915EA, DV4203TX, DV4203XX, DV4205TX, DV4206TX, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX, DV4214TX, DV4215TX, DV4217CL, DV4218TX, DV4220TX, DV4221TX, DV4222TX, DV4223CL, DV4223TX, DV4224EA, DV4225NR, DV4226TX, DV4230US, DV4230US-EC329UA, DV4231EA, DV4250US, DV4253US, DV4257US, DV4268EA, DV4269US, DV4270US, DV4272US, DV4275NR, DV4302EA, DV4304EA, DV4305EA, DV4305US, DV4306EA, DV4307CA, DV4307CL, DV4308WM, DV4309EA, DV4310US, DV4312EA, DV4315EA, DV4318EA, DV4320US, DV4321EA, DV4322EA, DV4324EA, DV4325EA, DV4326EA, DV4327EA, DV4330CA, DV4330US, DV4334EA, DV4335EA, DV4335NR, DV4336EA, DV4337EA, DV4339EA, DV4340US, DV4342EA, DV4344EA, DV4346EA, DV4348EA, DV4350EA, DV4351EA, DV4353EA, DV4354EA, DV4356EA, DV4357EA, DV4358EA, DV4360EA, DV4363EA, DV4364EA, DV4365EA, DV4367EA, DV4368EA, DV4376EA, DV4378EA, DV4379EA, DV4381EA, DV4383EA, DV4384EA, DV4385EA, DV4386EA, DV4388EA, DV4391EA, DV4392EA, DV4394EA, DV4395EA, DV4396EA, DV4398EA, DV4400, DV4401RS, DV4401XX, DV4402TU, DV4405NR, DV4410US, DV4419US, DV4420CA, DV4420US, DV4435EA, DV4440EA, DV4445EA, DV4450EA, DV5000, DV5000EA, DV5000T, DV5000Z, DV5001XX, DV5002EA, DV5003CL, DV5003EA, DV5005EA, DV5006EA, DV5007EA, DV5008EA, DV5009EA, DV5010EA, DV5011EA, DV5012EA, DV5016EA, DV5017CL, DV5017EA, DV5018EA, DV5020CA, DV5020US, DV5021EA, DV5022EA, DV5023EA, DV5024EA, DV5026EA, DV5027EA, DV5029US, DV5030US, DV5031EA, DV5033EA, DV5034EA, DV5035EA, DV5035NR, DV5036EA, DV5037EA, DV5040US, DV5041EA, DV5046EA, DV5047EA, DV5050EA, DV5051EA, DV5052EA, DV5053EA, DV5054EA, DV5055EA, DV5056EA, DV5057EA, DV5058EA, DV5059EA, DV5061EA, DV5062EA, DV5063EA, DV5074EA, DV5075EA, DV5077EA, DV5078EA, DV5084EA, DV5088XX, DV5091EA, DV5092EA, DV5093EA, DV5094EA, DV5095EA, DV5096EA, DV5097EA, DV5098EA, DV5099EA, DV5099XX, DV5100, DV5102EU, DV5104EU, DV5106EU, DV5107TX, DV5109TX, DV5110CA, DV5110TX, DV5110US, DV5111TU, DV5111TX, DV5113EU, DV5113TX, DV5114EU, DV5115EU, DV5115NR, DV5116EU, DV5116NR, DV5117CA, DV5117CL, DV5119EU, DV5119TX, DV5120EA, DV5120EU, DV5120LA, DV5120US, DV5121EA, DV5121EU, DV5122EA, DV5122TX, DV5123EA, DV5123TX, DV5124EU, DV5124TX, DV5125EU, DV5125TX, DV5127EU, DV5127TX, DV5128EU, DV5128TX, DV5129EU, DV5129US, DV5130CA, DV5130EU, DV5130TX, DV5130US, DV5131EU, DV5131TX, DV5132EU, DV5132TX, DV5134EA, DV5134EU, DV5135EU, DV5135NR, DV5136EU, DV5137EA, DV5139US, DV5140CA, DV5140EA, DV5140EU, DV5140US, DV5142EA, DV5143EA, DV5144EA, DV5145EA, DV5147EA, DV5148EA, DV5149EA, DV5149EU, DV5150EA, DV5150US, DV5155EU, DV5156EU, DV5157EA, DV5157EU, DV5158EU, DV5159EU, DV5161EU, DV5163CL, DV5164EA, DV5165EA, DV5166EA, DV5167CL, DV5170US, DV5173EA, DV5173EU, DV5174EU, DV5176EA, DV5176EU, DV5177EA, DV5178EA, DV5178US, DV5179EA, DV5186EU, DV5189EU, DV5189XX, DV5190EA, DV5190US, DV5191EA, DV5192EA, DV5193EA, DV5194EA, DV5196EA, DV5196XX, DV5197EA, DV5198EA, DV5198XX, DV5199XX, DV5200, DV5200TU, DV5201TX, DV5202TX, DV5203TX, DV5204TX, DV5205EA, DV5205TU, DV5205TX, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210EA, DV5210TX, DV5210US, DV5211EA, DV5211TX, DV5212TX, DV5213TX, DV5214TX, DV5215TX, DV5215US, DV5216CA, DV5216TX, DV5217CL, DV5218NR, DV5220LA, DV5220TX, DV5220US, DV5221TX, DV5222NR, DV5222TX, DV5223OM, DV5224NR, DV5224TX, DV5225EA, DV5225TX, DV5226TX, DV5229OM, DV5229TX, DV5230US, DV5233TX, DV5234US, DV5236OM, DV5237CL, DV5238EA, DV5239EA, DV5240US, DV5243EU, DV5250US, DV5252EA, DV5269EA, DV5270EA, DV5271EA, DV5272EA, DV5273EA, DV5278EA, DV5283EA, DV5284EA, DV5298XX, DV5299XX, DV5299XX, DV6000, DV6000T, DV6000Z, DV6001EA, DV6001XX, DV6002XX, DV6003EA, DV6003XX, DV6004EA, DV6005EA, DV6006EA, DV6007EA, DV6010EA, DV6011EA, DV6012EA, DV6013EA, DV6014EA, DV6015EA, DV6016EA, DV6017EA, DV6018EA, DV6019EA, DV6020EA, DV6021EA, DV6022EA, DV6023EA, DV6024EA, DV6025EA, DV6040CA, DV6040US, DV6045NR, DV6054EA, DV6057EA, DV6058CL, DV6058EA, DV6059EA, DV6060EA, DV6061EA, DV6062EA, DV6063EA, DV6064EA, DV6065EA, DV6067EA, DV6086EA, DV6087EA, DV6088EA, DV6095EA, DV6097EA, DV6100, DV6100EA, DV6101EA, DV6101EU, DV6101TU, DV6101TX, DV6101XX, DV6102EA, DV6102EU, DV6102OD, DV6102TX, DV6102XX, DV6103EA, DV6103EU, DV6103NR, DV6103TX, DV6103XX, DV6104EA, DV6104EU, DV6104NR, DV6104TX, DV6105CA, DV6105EA, DV6105EU, DV6105TX, DV6105US, DV6106EA, DV6106EU, DV6106TX, DV6107EA, DV6107EU, DV6107TX, DV6107US, DV6108EA, DV6108NR, DV6108TX, DV6108US, DV6109EA, DV6109NR, DV6109OM, DV6109TX, DV6110BR, DV6110CA, DV6110EA, DV6110EU, DV6110TX, DV6110US, DV6111EA, DV6111EU, DV6111NR, DV6111TX, DV6112EA, DV6112TX, DV6113CA, DV6113EA, DV6113EU, DV6113TX, DV6113US, DV6114EA, DV6114TX, DV6115CA, DV6115EA, DV6115EU, DV6115NR, DV6115TX, DV6116EA, DV6116EU, DV6116NR N, DV6116TX, DV6117EA, DV6117EU, DV6117TX, DV6118EA, DV6118EU, DV6118NR, DV6118TX, DV6119EA, DV6119EU, DV6119TX, DV6119US, DV6120BR, DV6120CA, DV6120EA, DV6120EU, DV6120LA, DV6120SE, DV6120TX, DV6120US, DV6121EA, DV6121EU, DV6121TX, DV6122EA, DV6122TX, DV6123EA, DV6123EU, DV6123TX, DV6124EA, DV6124EU, DV6124TX, DV6125BR, DV6125EA, DV6125OM, DV6125SE, DV6125TX, DV6126EA, DV6126EU, DV6126TX, DV6127EA, DV6127EU, DV6127TX, DV6128EA, DV6128EU, DV6128OD, DV6128TX, DV6129EA, DV6129EU, DV6129TX, DV6129US, DV6130CA, DV6130EA, DV6130EU, DV6130TX, DV6130US, DV6131EA, DV6131EU, DV6131OD, DV6131TX, DV6132EA, DV6132EU, DV6132TX, DV6133EA, DV6133EU, DV6133OD, DV6133TX, DV6134EA, DV6134EU, DV6134TX, DV6135CA, DV6135EA, DV6135EU, DV6135NR, DV6135TX, DV6136EA, DV6136EU, DV6136TX, DV6137EA, DV6137EU, DV6137TX, DV6138EA, DV6138EU, DV6138TX, DV6139EA, DV6139EU, DV6139TX, DV6139US, DV6140CA, DV6140EA, DV6140EU, DV6140TX, DV6140US, DV6141EA, DV6141EU, DV6141TX, DV6142EA, DV6142EU, DV6142TX, DV6143EA, DV6143EU, DV6143TX, DV6144EA, DV6144EU, DV6144TX, DV6145EA, DV6145EU, DV6145TX, DV6146EA, DV6146EU, DV6146TX, DV6147EA, DV6147EU, DV6147TX, DV6148EA, DV6148EU, DV6148TX, DV6149EA, DV6149EU, DV6149TX, DV6149US, DV6150BR, DV6150CA, DV6150EA, DV6150EU, DV6150TX, DV6150US, DV6151EA, DV6151EU, DV6152EA, DV6152EU, DV6153EA, DV6153EU, DV6154EA, DV6154EU, DV6155EA, DV6155EU, DV6156EA, DV6156EU, DV6157EA, DV6157EU, DV6158EA, DV6158EU, DV6159EA, DV6159EU, DV6160EA, DV6160EU, DV6161EA, DV6161EU, DV6162EA, DV6163EA, DV6164EA, DV6165CL, DV6165EA, DV6165EU,

DV6166EA, DV6167EA, DV6168EA, DV6169EA, DV6170EA, DV6171CL, DV6171EA, DV6172EA, DV6173EA,  
DV6174CA, DV6174CL, DV6174EA, DV6175EA, DV6179EA, DV6180EA, DV6181EA, DV6182EA, DV6182EU,  
DV6183EA, DV6184EA, DV6184EU, DV6185EA, DV6185EU, DV6186EA, DV6186EU, DV6187EA, DV6187EU,  
DV6188EA, DV6188EU, DV6189EA, DV6189EU, DV6190EU, DV6191EU, DV6195EA, DV6195XX, DV6196EA,  
DV6196XX, DV6197EA, DV6197XX, DV6198XX, DV6199XX, DV6200, DV6200EA, DV6200XX, DV6201EA, DV6201EU,  
DV6202EU, DV6203EA, DV6203TX, DV6204EA, DV6204EU, DV6205CA, DV6205EU, DV6205US, DV6206EA,  
DV6206US, DV6208EA, DV6208NR, DV6208TX, DV6210EA, DV6210TX, DV6211EA, DV6212EA, DV6213CL,  
DV6213EA, DV6214EA, DV6215CA, DV6215EA, DV6215TX, DV6215US, DV6216EA, DV6216TX, DV6217EA,  
DV6218EA, DV6218TX, DV6219EA, DV6220BR, DV6220EU, DV6221TX, DV6223EU, DV6225EU, DV6225US,  
DV6226US, DV6227CL, DV6230BR, DV6230EA, DV6231EA, DV6231EU, DV6233EA, DV6233SE, DV6235CA,  
DV6235EU, DV6235NR, DV6235US, DV6236EA, DV6236US, DV6237EA, DV6238EA, DV6239EA, DV6239EU,  
DV6240EU, DV6241EA, DV6241EU, DV6242EA, DV6242EU, DV6243CL, DV6243EA, DV6243EU, DV6244EA,  
DV6244EU, DV6244US, DV6245CA, DV6245EA, DV6245EU, DV6245US, DV6247CA, DV6247CL, DV6247EA,  
DV6248EU, DV6249EU, DV6250EU, DV6251EU, DV6252EU, DV6253CL, DV6253EU, DV6254EA, DV6254EU,  
DV6255CA, DV6255EU, DV6255US, DV6256EU, DV6256US, DV6258SE, DV6259EU, DV6260EU, DV6262EU,  
DV6263CL, DV6263EU, DV6264EU, DV6265CA, DV6265EA, DV6265EU, DV6265US, DV6266EU, DV6267CL,  
DV6267EU, DV6269EU, DV6274EA, DV6275EA, DV6275US, DV6276EA, DV6276EU, DV6277EA, DV6278EU,  
DV6280EA, DV6281EA, DV6283EU, DV6284EU, DV6285EU, DV6286EA, DV6286EU, DV6287EU, DV6288EA,  
DV6290EA, DV6291EA, DV6295EU, DV6297EA, DV6298EA, DV6299EA, DV6299XX, DV6300, DV6303TU, DV6305CA,  
DV6305US, DV6306RS, DV6307CA, DV6308CA, DV6308NR, DV6315CA, DV6324US, DV6325CA, DV6325US,  
DV6326US, DV6335CA, DV6335US, DV6337CL, DV6337US, DV6338SE, DV6340EU, DV6345US, DV6353CA,  
DV6353CL, DV6353US, DV6355CA, DV6355US, DV6357EU, DV6358SE, DV6363CA, DV6365US, DV6375US,  
DV6399XX, DV6400, DV6400A, DV6401CA, DV6401TU, DV6401TX, DV6401XX, DV6402CA, DV6402TU, DV6402XX,  
DV6403CL, DV6404CA, DV6404TX, DV6405CA, DV6405US, DV6406CA, DV6406NR, DV6407NR, DV6408CA,  
DV6408NR, DV6409CA, DV6409US, DV6409WM, DV6410CA, DV6415CA, DV6415US, DV6416CA, DV6418CA,  
DV6420LA, DV6422LA N, DV6423OM, DV6424CA, DV6425CA, DV6425US, DV6426CA, DV6426US, DV6427CL,  
DV6428CA, DV6433CL, DV6435CA, DV6436NR, DV6439NR, DV6445US, DV6446US, DV6447OM, DV6448SE,  
DV6449US, DV6450US, DV6451US, DV6452SE, DV6458SE, DV6470US, DV6499XX, DV6500, DV6500T, DV6500Z,  
DV6501AU, DV6501XX, DV6502XX, DV6503AU, DV6503TU, DV6504AU, DV6505AU, DV6505TU, DV6513TX,  
DV6514TX, DV6518TX, DV6520TX, DV6521TX, DV6523TX, DV6524TX, DV6531TX, DV6540TX, DV6541TX,  
DV6542TX, DV6545TX, DV6547EA, DV6550TX, DV6560US, DV6563CL, DV6565CA, DV6565US, DV6567CL,  
DV6568SE, DV6570US, DV6573CL, DV6575CA, DV6575US, DV6585CA, DV6589US, DV6597XX, DV6598XX,  
DV6599XX, DV6600, DV6601AU, DV6601TU, DV6601TX, DV6602AX, DV6603AX, DV6603CA, DV6604AU, DV6604CL,  
DV6604NR, DV6604TU, DV6604TX, DV6605CA, DV6605US, DV6607CL, DV6607NR, DV6607RS, DV6608CA,  
DV6609WM, DV6610TX, DV6611CA, DV6611TX, DV6612CA, DV6613TX, DV6615TX, DV6616TX, DV6618CA,  
DV6618TX, DV6619TX, DV6620LA, DV6620TX, DV6621TX, DV6622CA, DV6622TX, DV6623CL, DV6623TX,  
DV6624CA, DV6624TX, DV6625CA, DV6625TX, DV6625US, DV6626CA, DV6626TX, DV6626US, DV6627CA,  
DV6627NR, DV6627OM, DV6628TX, DV6628US, DV6629CA, DV6629TX, DV6629US, DV6629WM, DV6631CA,  
DV6633US, DV6634NR, DV6636NR, DV6640BR, DV6640US, DV6642CA, DV6643CL, DV6645CA, DV6645US,  
DV6646US, DV6647CL, DV6647NR, DV6648SE, DV6651XX, DV6652XX, DV6653CL, DV6654US, DV6660SE,  
DV6661SE, DV6662SE, DV6663CA, DV6663CL, DV6663US, DV6670CA, DV6672US, DV6675US, DV6693US,  
DV6696NR, DV6699XX, DV6700, DV6700T, DV6700Z, DV6701AX, DV6701CA, DV6701TU, DV6701TX, DV6701US,  
DV6701VX, DV6701XX, DV6702AU, DV6702AX, DV6702TU, DV6702TX, DV6702VX, DV6703AU, DV6703AX,  
DV6703TU, DV6703VX, DV6704AU, DV6704AX, DV6704CA, DV6704NR, DV6704TX, DV6704VX, DV6705AX,  
DV6705CA, DV6705TU, DV6705TX, DV6705VX, DV6706AU, DV6706AX, DV6707AX, DV6707TX, DV6707US,  
DV6708AX, DV6708TX, DV6709TX, DV6710AX, DV6710TX, DV6711AX, DV6713CA, DV6714CA, DV6714TX,  
DV6715TX, DV6716CA, DV6716TX, DV6717TX, DV6718CA, DV6718TX, DV6719TX, DV6720LA, DV6720TX,  
DV6721LA, DV6721TX, DV6722LA, DV6722TX, DV6724CA, DV6725CA, DV6725TX, DV6725US, DV6726TX,  
DV6727CA, DV6727TX, DV6728CA, DV6728TX, DV6729CA, DV6729TX, DV6729US, DV6730TX, DV6731TX,  
DV6732TX, DV6734TX, DV6735TX, DV6736NR, DV6736TX, DV6737TX, DV6739TX, DV6740TX, DV6742TX,  
DV6743TX, DV6744CA, DV6744TX, DV6745TX, DV6745US, DV6746CA, DV6747CL, DV6747NR, DV6748CA,  
DV6748US, DV6749TX, DV6750TX, DV6751TX, DV6751US, DV6751XX, DV6753CA, DV6753CL, DV6753TX,  
DV6754TX, DV6755CA, DV6755US, DV6756US, DV6757CA, DV6758US, DV6759TX, DV6762TX, DV6763TX,  
DV6764TX, DV6765TX, DV6766TX, DV6768TX, DV6769TX, DV6770SE, DV6770TX, DV6771TX, DV6772NR,  
DV6772TX, DV6775TX, DV6775US, DV6776TX, DV6777TX, DV6778TX, DV6779TX, DV6780CA, DV6780SE,  
DV6780TX, DV6781TX, DV6782TX, DV6783TX, DV6784TX, DV6785CA, DV6785SE, DV6785TX, DV6786TX,  
DV6787TX, DV6788TX, DV6789TX, DV6790TX, DV6791TX, DV6792TX, DV6793TX, DV6794TX, DV6795TX,  
DV6796TX, DV6798TX, DV6800, DV6801AX, DV6801CA, DV6801TU, DV6801TX, DV6802AX, DV6802TU, DV6802TX,  
DV6803AX, DV6803TU, DV6803TX, DV6804AX, DV6804TU, DV6804TX, DV6805CA, DV6805TU, DV6805TX,  
DV6806TX, DV6807TX, DV6807US, DV6808TX, DV6809US, DV6809WM, DV6810TX, DV6810US, DV6811TX,  
DV6812NR, DV6814CA, DV6815NR, DV6815TX, DV6816TX, DV6817TX, DV6818CA, DV6818TX, DV6819TX,  
DV6820TX, DV6821TX, DV6822TX, DV6823TX, DV6823US, DV6824CA, DV6824TX, DV6825CA, DV6825TX,  
DV6827CA, DV6827TX, DV6828TX, DV6829TX, DV6830TX, DV6830US, DV6831TX, DV6832TX, DV6833TX,  
DV6833US, DV6834CA, DV6834TX, DV6835CA, DV6835NR, DV6835TX, DV6836TX, DV6837CL, DV6837TX,  
DV6838CA, DV6838NR, DV6838TX, DV6839CL, DV6839TX, DV6840TX, DV6841TX, DV6847TX, DV6848TX,  
DV6851XX, DV6853CA, DV6853CL, DV6854CA, DV6858CA, DV6864CA, DV6870US, DV6871US, DV6872LA,  
DV6874CA, DV6875CA, DV6875SE, DV6880SE, DV6883CL, DV6884CA, DV6885CA, DV6885SE, DV6898CA,  
DV6899XX, DV6900, DV6901TU, DV6901TX, DV6902TU, DV6902TX, DV6903TU, DV6903TX, DV6904CA, DV6907CA,  
DV6907TX, DV6908TX, DV6909TX, DV6910CA, DV6911OM, DV6911US, DV6912TX, DV6913CA, DV6913RS,

DV6915CA, DV6915NR, DV6916TX, DV6917CL, DV6917NR, DV6917TX, DV6918SE, DV6918TX, DV6919CA, DV6919TX, DV6920TX, DV6921TX, DV6923TX, DV6926NR, DV6928US, DV6929NR, DV6929WM, DV6930US, DV6933CL, DV6934CA, DV6935CA, DV6936US, DV6937CL, DV6938SE, DV6939CA, DV6940SE, DV6948CA, DV6958SE, DV6968CA, DV6974CA, DV6976CA, DV6985SE, DV6988CA, DV6995LA, DV6998CA, DV8000, DV8000T, DV8000Z, DV8002EA, DV8005EA, DV8010EA, DV8013CL, DV8013XX, DV8027EA, DV8028EA, DV8029EA, DV8035EA, DV8040US, DV8040XX, DV8045EA, DV8051EA, DV8075EA, DV8088US, DV8099XX, DV80XXUS, DV8100, DV8102EA, DV8110US, DV8113CL, DV8113EA, DV8114EA, DV8116EA, DV8117EA, DV8120CA, DV8125NR, DV8130US, DV8135EA, DV8135NR, DV8140US, DV8155EA, DV8173EA, DV8175EA, DV8176EA, DV8177EA, DV8178EA, DV8179EA, DV8195EA, DV8197EA, DV8199EA, DV81XXUS, DV8200, DV8201TX, DV8202TX, DV8203TX, DV8204TX, DV8205TX, DV8206TX, DV8207TX, DV8208TX, DV8209TX, DV8210CA, DV8210EA, DV8210US, DV8211EA, DV8211EU, DV8212EA, DV8213CL, DV8213EA, DV8214EA, DV8214TX, DV8215EA, DV8215TX, DV8219EA, DV8220CA, DV8220EA, DV8220US, DV8221EA, DV8222EA, DV8223EA, DV8225CA, DV8225EA, DV8225NR, DV8226EA, DV8227EA, DV8228EA, DV8229EA, DV8230CA, DV8230EA, DV8230US, DV8231EA, DV8233CL, DV8233EA, DV8235EA, DV8235NR, DV8240US, DV8251EA, DV8252EU, DV8253EA, DV8254EA, DV8260EA, DV8275EA, DV8275LA, DV8279EA, DV8280EA, DV8280US, DV8286EA, DV8287EA, DV8289EA, DV8289XX, DV8290EA, DV8291EA, DV8292EA, DV8293EA, DV8294EA, DV8295EA, DV8298EA, DV8298XX, DV8299XX, DV8300, DV8300TX, DV8301NR, DV8301TX, DV8302TX, DV8304TX, DV8305CA, DV8305TX, DV8305US, DV8306EA, DV8306TX, DV8307EA, DV8307TX, DV8309US, DV8310US, DV8312TX, DV8314TX, DV8315NR, DV8315TX, DV8318TX, DV8320EA, DV8320US, DV8321TX, DV8322EA, DV8323EA, DV8325EA, DV8327CA, DV8327CL, DV8327US, DV8328CA, DV8333CL, DV8339US, DV8375LA, DV8379EA, DV8380US, DV8382EA, DV8389EA, DV8390EA, DV8391EA, DV8393EA, DV8395EA, DV8398EA, DV8399XX, DV8400, DV8408US, DV9000, DV9000EA, DV9000T, DV9001EA, DV9001XX, DV9002EA, DV9002NR, DV9002XX, DV9003EA, DV9003TX, DV9003XX, DV9004EU, DV9004TX, DV9004XX, DV9005CA, DV9005EA, DV9005TX, DV9005US, DV9005XX, DV9006EA, DV9006OM, DV9006TX, DV9008EA, DV9008NR, DV9009CA, DV9009CL, DV9009NR, DV9009TX, DV9009US, DV9010CA, DV9010TX, DV9010US, DV9011TX, DV9012TX, DV9013CA, DV9013CL, DV9013TX, DV9014EA, DV9014TX, DV9015EA, DV9015TX, DV9016EA, DV9016TX, DV9017EA, DV9017TX, DV9018EA, DV9019EA, DV9019TX, DV9020TX, DV9021TX, DV9022EA, DV9022TX, DV9023US, DV9024EA, DV9030EA, DV9030US, DV9035EA, DV9035NR, DV9036EA, DV9037EA, DV9038EA, DV9039EA, DV9040EA, DV9040EU, DV9040US, DV9041EA, DV9042EA, DV9043EA, DV9044EA, DV9045EA, DV9046EA, DV9048EA, DV9049EA, DV9050EA, DV9051EA, DV9052EA, DV9053EA, DV9055EA, DV9056EA, DV9057EA, DV9058EA, DV9059EA, DV9060EA, DV9060US, DV9061EA, DV9062EA, DV9063EA, DV9064EA, DV9065EA, DV9066EA, DV9067EA, DV9068EA, DV9069EA, DV9071EA, DV9072EA, DV9073EA, DV9074CL, DV9074EA, DV9075EA, DV9075EU, DV9075LA, DV9076EA, DV9076EU, DV9077EA, DV9077EU, DV9078EA, DV9079EA, DV9080EA, DV9081EA, DV9082EA, DV9082EU, DV9083EA, DV9084EA, DV9085EA, DV9086EA, DV9087EA, DV9088EA, DV9089EA, DV9090EA, DV9091EA, DV9092EA, DV9093EA, DV9093EU, DV9094EA, DV9095EU, DV9095XX, DV9096EA, DV9096XX, DV9097EA, DV9097XX, DV9098XX, DV9099EA, DV9099XX, DV9100, DV9200, DV9200XX, DV9201CA, DV9201TX, DV9202EA, DV9202TX, DV9204TX, DV9205CA, DV9205EU, DV9205US, DV9206EU, DV9206TX, DV9207TX, DV9207US, DV9208NR, DV9208TX, DV9209TX, DV9210CA, DV9210TX, DV9210US, DV9211EA, DV9211TX, DV9212EA, DV9212TX, DV9213EA, DV9213TX, DV9214EA, DV9214TX, DV9215TX, DV9216EA, DV9216TX, DV9217EA, DV9217TX, DV9218EA, DV9218TX, DV9219EA, DV9219TX, DV9220CA, DV9220EU, DV9220TX, DV9220US, DV9221EA, DV9221TX, DV9225US, DV9230US, DV9231CA, DV9232EU, DV9233CA, DV9233CL, DV9233EU, DV9235NR, DV9237EU, DV9241EA, DV9243EA, DV9244EA, DV9244EU, DV9248EA, DV9252EU, DV9253EA, DV9254EU, DV9255EA, DV9260NR, DV9260US, DV9265EA, DV9265LA, DV9266EA, DV9266EU, DV9267EA, DV9268EA, DV9269EA, DV9271EA, DV9272EA, DV9273EA, DV9274EU, DV9275EA, DV9275LA, DV9276EA, DV9283EA, DV9285EA, DV9286EA, DV9287CL, DV9288EA, DV9289EA, DV9291EA, DV9292EU, DV9293EA, DV9294EA, DV9294EU, DV9295EA, DV9295EU, DV9296EA, DV9296EU, DV9297EA, DV9299EA, DV9299XX, DV9300, DV9301TX, DV9302TX, DV9303EU, DV9303TX, DV9304EU, DV9304TX, DV9305EU, DV9306TX, DV9307TX, DV9308EA, DV9308NR, DV9308TX, DV9309EA, DV9309EU, DV9309TX, DV9310CA, DV9310EA, DV9310EU, DV9310TX, DV9310US, DV9311EA, DV9311EU, DV9311TX, DV9312EA, DV9312TX, DV9313EA, DV9314EA, DV9315CA, DV9315EA, DV9316EA, DV9317CA, DV9317CL, DV9317EA, DV9318CA, DV9318EA, DV9319EA, DV9320CA, DV9320EA, DV9320US, DV9321EA, DV9322EA, DV9324EA, DV9330CA, DV9330US, DV9331EU, DV9332EA, DV9332EU, DV9334US, DV9335NR, DV9337EU, DV9338EU, DV9339US, DV9340EA, DV9341EU, DV9342EU, DV9343CA, DV9343EU, DV9344EU, DV9345EU, DV9346EA, DV9347CL, DV9348EA, DV9350EA, DV9351EA, DV9361EA, DV9362EA, DV9363EA, DV9372EU, DV9374EU, DV9375EU, DV9377EA, DV9378EA, DV9379EA, DV9380CA, DV9380EA, DV9381EA, DV9385EA, DV9389EA, DV9390EA, DV9391EU, DV9392EA, DV9393EA, DV9394EA, DV9395EA, DV9396EA, DV9397EA, DV9398EA, DV9398EA, DV9399EA, DV9400, DV9401XX, DV9407NR, DV9408CA, DV9408NR, DV9410CA, DV9410US, DV9413CL, DV9417CA, DV9417CL, DV9418CA, DV9420CA, DV9420US, DV9428CA, DV9428NR, DV9429US, DV9438CA, DV9443CA, DV9500, DV9500EW, DV9501AU, DV9501XX, DV9502XX, DV9503AU, DV9505TX, DV9507TX, DV9508TX, DV9509TX, DV9511TX, DV9512TX, DV9513TX, DV9515CA, DV9515EF, DV9515EO, DV9516TX, DV9518EM, DV9518TX, DV9519TX, DV9520EB, DV9520TX, DV9521EJ, DV9521TX, DV9522TX, DV9525EN, DV9525EO, DV9525US, DV9530EB, DV9530EF, DV9530EM, DV9532EM, DV9533EF, DV9535NR, DV9535US, DV9540EB, DV9540US, DV9541EV, DV9542EV, DV9543CL, DV9543EV, DV9547CL, DV9548CA, DV9548US, DV9550EO, DV9550EP, DV9552ES, DV9555EG, DV9560EA, DV9560EG, DV9560ER, DV9562EZ, DV9565EG, DV9570EL, DV9570EO, DV9572EA, DV9574EA, DV9574LA, DV9575EF, DV9575EM, DV9575EN, DV9575EO, DV9575EP, DV9575ES, DV9575LA, DV9575NR, DV9576EA, DV9580EE, DV9580EG, DV9580EL, DV9580EN, DV9580EO, DV9580ET, DV9580EZ, DV9580US, DV9581EE, DV9585EG, DV9585EL, DV9588EF, DV9590EA, DV9590ED, DV9590EG, DV9590ER, DV9590ET, DV9590EZ, DV9592EF, DV9595EA, DV9595ED, DV9596XX, DV9597XX, DV9598XX, DV9599XX, DV9600, DV9601AU, DV9601TX, DV9602AU, DV9602TX, DV9603AU,



DV9603TX, DV9604AU, DV9604TX, DV9605EF, DV9605EM, DV9605EO, DV9605TX, DV9606CA, DV9606TX, DV9607TX, DV9607US, DV9608CA, DV9608ES, DV9608NR, DV9608TX, DV9610CA, DV9610EB, DV9610EF, DV9610EM, DV9610ET, DV9610EV, DV9610TX, DV9610US, DV9611TX, DV9612CA, DV9612TX, DV9613TX, DV9614CA, DV9614TX, DV9615CA, DV9615TX, DV9616CA, DV9616TX, DV9617NR, DV9617TX, DV9618CA, DV9620EN, DV9620ET, DV9620US, DV9623CA, DV9623CL, DV9623ED, DV9625CA, DV9625ER, DV9625EW, DV9626US, DV9627CL, DV9628CA, DV9628NR, DV9629CA, DV9630EB, DV9630ED, DV9630EF, DV9630ET, DV9631EF, DV9631EM, DV9634CA, DV9635CA, DV9635EF, DV9635EM, DV9638US, DV9639EO, DV9640CA, DV9640US, DV9643EO, DV9644CA, DV9645ED, DV9645EF, DV9645EM, DV9645EO, DV9646EM, DV9647EF, DV9647EM, DV9649EF, DV9649EM, DV9650ES, DV9650US, DV9651XX, DV9652XX, DV9653CL, DV9655EA, DV9655EO, DV9655EZ, DV9657CL, DV9657EM, DV9657EO, DV9658EA, DV9660EB, DV9660EF, DV9660EG, DV9660EI, DV9660EV, DV9665EL, DV9665EO, DV9667EA, DV9670ED, DV9670EE, DV9670EF, DV9670EL, DV9670EM, DV9670EO, DV9675EG, DV9675EL, DV9675EO, DV9680ED, DV9680EF, DV9680EP, DV9680EV, DV9680EW, DV9680EZ, DV9681ER, DV9682EG, DV9684EG, DV9685EO, DV9686EO, DV9687EO, DV9688EG, DV9689EA, DV9690EE, DV9690EI, DV9690EL, DV9690EN, DV9690EV, DV9690EW, DV9690EZ, DV9691EG, DV9694EG, DV9695EA, DV9695EF, DV9695EG, DV9695EL, DV9695EO, DV9698EO, DV9699EF, DV9700, DV9700T, DV9700Z, DV9701AU, DV9701AX, DV9701TX, DV9701XX, DV9702AU, DV9702AX, DV9702TX, DV9702XX, DV9703AX, DV9703TX, DV9703XX, DV9704AX, DV9704TX, DV9705AX, DV9705TX, DV9706AX, DV9706TX, DV9711TX, DV9712TX, DV9714TX, DV9715NR, DV9715TX, DV9716TX, DV9717TX, DV9718TX, DV9719TX, DV9720CA, DV9720TX, DV9720US, DV9723CA, DV9723CL, DV9724CA, DV9727CL, DV9727TX, DV9727US, DV9728CA, DV9728CL, DV9728TX, DV9729TX, DV9730CA, DV9730NR, DV9730TX, DV9730US, DV9731CA, DV9732TX, DV9733TX, DV9734NR, DV9735TX, DV9736CA, DV9736TX, DV9737TX, DV9738TX, DV9740CA, DV9740TX, DV9740US, DV9741TX, DV9742TX, DV9743CL, DV9744TX, DV9744TX, DV9745TX, DV9746TX, DV9747CL, DV9747TX, DV9748CA, DV9750US, DV9751XX, DV9758CA, DV9770LA, DV9774CA, DV9775LA, DV9780LA, DV9785LA, DV9800, DV9803TX, DV9804CA, DV9808CA, DV9808TX, DV9809TX, DV9810CA, DV9810TX, DV9810US, DV9811TX, DV9812TX, DV9812US, DV9813TX, DV9814TX, DV9815NR, DV9815TX, DV9817CL, DV9818TX, DV9819TX, DV9819WM, DV9820TX, DV9820US, DV9821TX, DV9822TX, DV9823CA, DV9823CL, DV9823TX, DV9824CA, DV9825NR, DV9827CL, DV9830US, DV9831CA, DV9834CA, DV9838CA, DV9843CL, DV9847CA, DV9851XX, DV9854CA, DV9858CA, DV9894CA, DV9899XX, DV9900, DV9901TX, DV9903CA, DV9904CA, DV9907CA, DV9908CA, DV9910CA, DV9910US, DV9912NR, DV9913CL, DV9917CL, DV9920US, DV9922US, DV9924CA, DV9925NR, DV9927CL, DV9930US, DV9933CA, DV9933CL, DV9933NR, DV9934CA, DV9999US, DX6600, DX6650CA, DX6650US, DX6653CA, DX6665CA, DX6667CL, DX6697US, DX6699XX, G3000, G3000EA, G3050EA, G3100, G5000, G5001TU, G5002TU, G5003EA, G5009EA, G5040EA, G5042EA, G5050, G5050XX, G5051TU, G6000, G6000XX, G7000, G7001TU, G7002TU, G7030, G7030XX, G7031TU, G7032TU, G7060, G7061TU, G7091TU, TX1000, TX1001XX, TX1002XX, TX1003XX, TX1017AU, TX1020EA, TX1021AU, TX1030EA, TX1040EA, TX1070BR, TX1080EA, TX1100, TX1110CA, TX1110US, TX1115NR, TX1119US, TX1120US, TX1127CL, TX1200, TX1201XX, TX1202AU, TX1202XX, TX1205US, TX1206AU, TX1208CA, TX1210CA, TX1210US, TX1215NR, TX1217CL, TX1218AU, TX1218CA, TX1219US, TX1220AU, TX1220CA, TX1220US, TX1228CA, TX1230LA, TX1232LA, TX1304AU, TX1304CA, TX1305AU, TX1305CA, TX1305US, TX1306NR, TX1307AU, TX1308CA, TX1308NR, TX1313AU, TX1314AU, TX1314CA, TX1315AU, TX1316AU, TX1317AU, TX1318AU, TX1318CA, TX1319AU, TX1320AU, TX1320CA, TX1320US, TX1321AU, TX1325NR, TX1327CL, TX1330LA, TX1332LA, TX1400, TX1401AU, TX1403AU, TX1404AU, TX1410US, TX1414CA, TX1416CA, TX1417CL, TX1418CA, TX1419NR, TX1420CA, TX1420US, TX1499US, TX2000, TX2000Z, TX2002AU, TX2003AU, TX2005AU, TX2006AU, TX2008AU, TX2010AU, TX2013AU, TX2014AU, TX2015AU, TX2016AU, TX2018AU, TX2019AU, TX2020AU, TX2021AU, TX2023AU, TX2024AU, TX2025AU, TX2026AU, TX2027AU, TX2030AU, TX2031AU, TX2032LA, TX2033AU, TX2051XX, TX2052XX, TX2053XX, TX2054XX, TX2104AU, TX2104CA, TX2105, TX2105AU, TX2106AU, TX2107AU, TX2108AU, TX2108CA, TX2109AU, TX2110AU, TX2110CA, TX2110US, TX2113CL, TX2114CA, TX2115NR, TX2117CL, TX2120US, TX2151XX, TX2152XX, TX2500, TX2500Z, TX2501AU, TX2504AU, TX2507AU, TX2508AU, TX2508CA, TX2510AU, TX2510CA, TX2511AU, TX2512AU, TX2513AU, TX2513CL, TX2514AU, TX2514CA, TX2516AU, TX2517AU, TX2517CA, TX2517CL, TX2518AU, TX2519AU, TX2520AU, TX2521AU, TX2524CA, TX2525AU, TX2525NR, TX2526AU, TX2527AU, TX2528AU, TX2532AU, TX2534AU, TX2551XX, TX2552XX, TX2601AU, TX2604AU, TX2604CA, TX2605AU, TX2608AU, TX2608CA, TX2609AU, TX2610AU, TX2611AU, TX2612AU, TX2614AU, TX2615AU, TX2616AU, TX2617CA, TX2622NR, TX2623CA, TX2635US, TX2697CL, V9500T, V9500Z, X1000, X1000Z, ZE2000, ZE2000-PM341AV, ZE2000-PM342AV, ZE2000T, ZE2000T-PQ648AV, ZE2000Z, ZE2000Z-PV336AV, ZE2000Z-PV337AV, ZE2001AP-PS928PA, ZE2001EA-PS723EA, ZE2001EA-PS733EA, ZE2001XX, ZE2002AP-PT362PA, ZE2002EA-PS728EA, ZE2003AP-PT363PA, ZE2004AP-PT369PA, ZE2004US, ZE2004US-PX390UA, ZE2005AP-PT519PA, ZE2005EA-PW956EA, ZE2005US, ZE2006AP-PT520PA, ZE2007AP-PT521PA, ZE2007EA-PS735EA, ZE2008AP-PT522PA, ZE2008WM, ZE2008WM-X391UA, ZE2009AP-PT523PA, ZE2010AP, ZE2010AP-PT532PA, ZE2010BR, ZE2010BR-PX285LA, ZE2010EA-PS721EA, ZE2011AP, ZE2011AP-PT533PA, ZE2012AP, ZE2012AP-PT539PA, ZE2013AP, ZE2013AP-PT540PA, ZE2014AP, ZE2014AP-PV278PA, ZE2015AP, ZE2015AP-PV283PA, ZE2015EA-PS722EA, ZE2015US, ZE2015US-PX382UA, ZE2016AP, ZE2016AP-PV284PA, ZE2017AP, ZE2017AP-PV285PA, ZE2018AP, ZE2018AP-PV293PA, ZE2019AP-PY858PA, ZE2020AP-PY859PA, ZE2020BR, ZE2020BR-PX286LA, ZE2020CA, ZE2020CA-PX387UA, ZE2020EA-PS737EA, ZE2020EA-PW955EA, ZE2021EA-PW952EA, ZE2022AP, ZE2022EA-PW949EA, ZE2023EA-PW962EA, ZE2024EA-PW947EA, ZE2025EA-PS726EA, ZE2025EA-PS738EA, ZE2026EA-PS724EA, ZE2027EA-PS736EA, ZE2028EA-PS727EA, ZE2030BR, ZE2030BR-PX287LA, ZE2039EA-PS729EA, ZE2040BR, ZE2040BR-PX288LA, ZE2040EA-PS720EA, ZE2044EA-PW959EA, ZE2044EA-PW961EA, ZE2045EA-PS734EA, ZE2050EA-PW948EA, ZE2050EA-PW963EA, ZE2055EA-PS730EA, ZE2058EA-PW958EA, ZE2060EA-PS725EA, ZE2062EA-PW954EA, ZE2062EA-PW960EA, ZE2068EA-PS732EA, ZE2070EA-PS719EA, ZE2070EA-PS731EA, ZE2090EA-PW951EA, ZE2091EA-PW957EA, ZE2099XX, ZE2108WM, ZE2109US, ZE2110US, ZE2113US, ZE2114US, ZE2115US, ZE2117US, ZE2200, ZE2201XX, ZE2202XX, ZE2204AP, ZE2204AU, ZE2206AU,

ZE2207AP, ZE2207AU, ZE2208AP, ZE2209XX, ZE2210AU, ZE2210BR, ZE2211AP, ZE2211AU, ZE2212AP, ZE2213TU, ZE2215TU, ZE2216TU, ZE2220BR, ZE2250EA, ZE2296XX, ZE2297XX, ZE2298XX, ZE2299XX, ZE2300, ZE2308, ZE2308EA, ZE2308WM, ZE2309NR, ZE2315, ZE2315US, ZE2320LA, ZE2372EA, ZE2401EA, ZE2401XT, ZE2405EA, ZE2409EA, ZE2410EA, ZE2415EA, ZE2500, ZE2505AU, ZE2506AU, ZE4900, ZT3000, ZT3001US, ZT3010, ZT3010AP, ZT3010EA, ZT3010US, ZT3011AP, ZT3012EA, ZT3013AP, ZT3014AP, ZT3015AP, ZT3015EA, ZT3016AP, ZT3017AP, ZT3017EA, ZT3017WM, ZT3018AP, ZT3019AP, ZT3019EA, ZT3020, ZT3020AP, ZT3020EA, ZT3020US, ZT3021AP, ZT3022AP, ZT3022EA, ZT3023AP, ZT3024AP, ZT3024EA, ZT3025AP, ZT3026AP, ZT3027AP, ZT3028AP, ZT3029AP, ZT3030AP, ZT3030EA, ZT3031AP, ZT3032AP, ZT3033AP, ZT3034AP, ZT3035AP, ZT3036AP, ZT3037AP, ZT3038AP, ZT3039AP, ZT3040AP, ZT3041AP, ZT3043AP, ZT3044AP, ZT3045AP, ZT3046AP, ZT3047AP, ZT3048AP, ZT3049AP, ZT3050AP, ZT3050EA, ZT3051AP, ZT3068CL, ZT3101EA, ZT3101US, ZT3105EA, ZT3106EA, ZT3110EA, ZT3111EA, ZT3113EA, ZT3114EA, ZT3115EA, ZT3116EA, ZT3120EA, ZT3130EA, ZT3131EA, ZT3140US, ZT3170US, ZT3200, ZT3201US, ZT3202AP, ZT3206AP, ZT3207AP, ZT3208AP, ZT3209AP, ZT3210AP, ZT3210EA, ZT3211AP, ZT3211EA, ZT3212AP, ZT3213AP, ZT3214AP, ZT3214EA, ZT3215AP, ZT3215EA, ZT3216AP, ZT3217AP, ZT3218AP, ZT3219AP, ZT3220AP, ZT3221AP, ZT3222AP, ZT3225AP, ZT3228AP, ZT3229AP, ZT3230AP, ZT3231AP, ZT3232AP, ZT3232EA, ZT3235AP, ZT3236AP, ZT3237AP, ZT3239EA, ZT3240EA, ZT3241EA, ZT3242EA, ZT3250, ZT3250US, ZT3260EA, ZT3280US, ZT3300, ZT3301AP, ZT3301US, ZT3302AP, ZT3302US, ZT3303AP, ZT3304AP, ZT3305AP, ZT3306AP, ZT3307AP, ZT3308AP, ZT3309AP, ZT3311AP, ZT3312AP, ZT3313AP, ZT3314AP, ZT3315AP, ZT3316AP, ZT3317AP, ZT3318AP, ZT3319AP, ZT3320AP, ZT3321AP, ZT3323AP, ZT3325AP, ZT3326AP, ZT3327AP, ZT3328AP, ZT3330AP, ZT3331AP, ZT3332AP, ZT3338AP, ZT3339AP, ZT3340US, ZT3341AP, ZT3343AP, ZT3344AP, ZT3345AP, ZT3346AP, ZT3348AP, ZT3349AP, ZT3349CL, ZT3350AP, ZT3350US, ZT3351AP, ZT3354AP, ZT3355AP, ZT3355US, ZT3358AP, ZT3359AP, ZT3380US, ZT3380XX, ZT3400, ZT4000, ZT4900,

#### Special Edition series

L2000, L2005A3, L2005A4, L2005CL, L2005CM, L2005CO, L2005CU, L2005CX, L2005US, L2098XX, L2099XX, L2105CA, L2105CL, L2105NR, L2205NR, L2300, L2310CU,

#### Voodoo Envy series

133 NV4010NA, 133 NV4015NA, 133 NV4020NA, 133 NV4040NA, 133 NV4045NA, 133 NV4050NA, 133 NV4070NA, 133 NV4075NA, 133 NV4080NA,

18.5V2.7A 4.8mm\*1.7mm 50W

#### Compaq

##### Armada series

110, E500, E500S, E700, M300, M700, SB, V300,

##### Evo series

N110, N115, N150, N160, N180, N200, N400C, N410C, N600, N600C, N610, N610C, N610V, N620C,

##### LTE series

ELITE, LITE,

##### Presario series

1500, 2800, 2800AP, 2800AU, 2800CA, 2800EA, 2800SC, 2800TC, 2800US, 2801AP, 2801EA, 2801SC, 2801TC, 2802AP, 2802EA, 2802SC, 2802TC, 2803TC, 2804SC, 2804TC, 2805AP, 2805AU, 2805EA, 2805TC, 2805US, 2806AP, 2806EA, 2806SC, 2807AP, 2808EA, 2809AP, 2809FR, 2810AP, 2810AU, 2810CA, 2810EA, 2810LA, 2810SC, 2810TC, 2811AP, 2811EA, 2811SW, 2812AP, 2812AU, 2812SP, 2812TC, 2813TC, 2814AP, 2814AU, 2815AP, 2815AU, 2815EA, 2815LA, 2815SP, 2815TC, 2816EA, 2816KR, 2816TC, 2817AP, 2817AR, 2817EA, 2817KR, 2817TC, 2818AP, 2818FR, 2818KR, 2818TC, 2819AP, 2819TC, 2820AP, 2820AU, 2820EA, 2820SC, 2820TC, 2821AP, 2821AU, 2821DE, 2821EA, 2821SC, 2821TC, 2822AP, 2822EA, 2822TC, 2823AP, 2823AU, 2823TC, 2824AP, 2824TC, 2825AP, 2825EA, 2825TC, 2826AP, 2826EA, 2826TC, 2827AP, 2827TC, 2828AP, 2828TC, 2829AP, 2829TC, 2830AP, 2830AU, 2830EA, 2830SC, 2830TC, 2831AP, 2831SC, 2831TC, 2832AP, 2832SC, 2832TC, 2833TC, 2834TC, 2835AP, 2835EA, 2836AP, 2836TC, 2837AP, 2837EA, 2837TC, 2838AP, 2838TC, 2839AP, 2839TC, 2840AP, 2840TC, 2841AP, 2842AP, 2843AP, 2844AP, 2845AP, 2846AP, 2850AP, 2851AP, 2852AP, 2853AP, 2854AP, 2855AP, 2856AP, 2857AP, 2858AP, 2859AP, 2860AP, 2861AP, 2862AP, 2863AP, 2864AP, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2872AP, 2873AP, 2874AP, 2875AP, 2876AP, 2877AP, 2878AP, 2878CL, 2879AP, 2879CL, 2880AP, 2880CL, 2881CL, 2882AP, 2883AP,

2884AP, 2885AP, 2886AP, 2887AP, 2888AP, 2889AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 300, 900, 900LA, 900US, 900XX, 901AP, 901EA, 901XX, 902AP, 902AU, 902EA, 902FR, 902XX, 903AP, 903EA, 903KR, 903TU, 903XX, 904AP, 905AP, 905AU, 905LA, 905TC, 905US, 906EA, 906US, 907AP, 908EA, 908TU, 909EA, 910AP, 910EA, 910US, 912EA, 912RSH, 914EA, 915US, 916US, 917DE, 918RSH, 920AP, 920CA, 920EA, 921AP, 922UK, 923AP, 925AP, 925EA, 927AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP, A900,

Prosignia series

120, 122, 124, 140, 142, 144, 150, 160, 161, 162, 165, 170, 190, 486, 586,